



548

Showcase Merchandiser

Field Service Manual
And
Parts Catalog

Part Number 900-54805 D
Fourth Edition

548 Showcase Merchandiser

Field Service Manual and Parts Catalog

This manual contains all of the necessary information needed to install, operate and perform basic service on the 548 Showcase Merchandiser. The front section contains vendor specifications and a table of contents. The description section reviews the major components of the vendor along with a more detailed discussion on the slide in-slide out refrigeration system. The service mode operation section contains an itemized description of how to program the machine's features. The troubleshooting section contains a preliminary checklist, a power supply light indicator table and two troubleshooting charts and wiring schematics. The parts section has illustrations that call out service and replacement parts for the 548 Showcase Merchandiser.

Part Number 900-54805 D
Fourth Edition
First Printing March, 1996
Printed in U.S.A.

SPECIFICATIONS:

548 Showcase Merchandiser

GENERAL

| | |
|--|------------|
| Depth | 35 5/8 in. |
| Width | 41 in. |
| Height | 72 in. |
| Net Weight | 790 lb. |
| Shipping Weight | 840 lb. |
| Maximum Location Ambient Temperature | 110° F |

POWER REQUIREMENTS

| | | |
|-----------------|---------|-------------|
| Voltage | 120 VAC | 220/240 VAC |
| Current | 16 AMPS | 10 AMPS |
| Frequency | 60 HZ | 50/60 HZ |

VEND CAPACITY

| | |
|------------------------------------|-----------------------|
| Total Items | 154 MAX. |
| Delivery Doors | 11 |
| Delivery Door Dimensions (Nominal) | |
| 9 Doors | 4 in Height |
| 2 Doors | 5 in Height |
| 11 Doors | 6 or 9 in. Width |
| Compartment Depth (Nominal) | 9 1/4 in. Depth |
| Shelf Configurations Available: | |
| Over/Under | 14 Products Per Shelf |
| Plain | 7 Products Per Shelf |
| Vertical Split | 14 Products Per Shelf |
| Food Compartment | |
| Operating Temperatures | 38° ± 4° F |

COIN MECHANISMS

120V Models-12 or 15 Pin

| | |
|--------------|------------|
| MARS | TRC - 6000 |
| COINCO | 9300L |

24 V Models-15 Pin Only

| | |
|--------------|-----------------|
| MARS | TRC - 6010 - XV |
| COINCO | 9302LF |

CAUTION !

Do not use 24 volt Coin Mech with 12 pin plugs! This will result in permanent damage to the Coin Mech and/or vending machine.

REFRIGERATION SYSTEM

120 V

| | |
|---------------------------|-------------------|
| Type | 3/4 HP Air Cooled |
| Charge | R404a (18oz.) |
| Operating Pressures | @ 75° F |
| High Side : | 200 - 240 psig |
| Low Side : | 23 - 25 psig |
| Test Pressures: | 300 psig |

220/240 V

| |
|-------------------|
| 3/4 HP Air Cooled |
| R404a (510 Grams) |
| @ 24° C |
| 1440-1579 KPA |
| 137-151 KPA |

CAUTION !

This system is charged with R404a Refrigerant.

Table Of Contents

| | |
|------------------------|------|
| Specifications | vi |
| Coin Mech. Chart | viii |
| Features | ix |

SECTION 1

DESCRIPTION

| | |
|------------------------------|-----|
| Introduction | 1-1 |
| Major Components | 1-1 |
| Refrigeration | 1-2 |
| Point of Sale Messages | 1-5 |

SECTION 2

INSTALLATION

| | |
|------------------------------|-----|
| Introduction | 2-1 |
| Unpacking Instructions | 2-1 |
| Set-Up Instructions | 2-1 |
| Coin Mech Loading | 2-2 |
| Pre-Operation Check | 2-3 |

SECTION 3

SERVICE MODE OPERATION

| | |
|--------------------------------|------|
| Introduction | 3-1 |
| Blind Operator Feature | 3-1 |
| Basic Program Set-Up | 3-2 |
| Filling The Turret | 3-3 |
| Factory Default Settings | 3-4 |
| Quick-Reference Guide | 3-5 |
| Mini Menu Flowchart | 3-6 |
| Full Menu Flowchart | 3-7 |
| Price Menu | 3-8 |
| MIS Menu | 3-10 |
| Options Menu | 3-17 |
| Clock Menu | 3-23 |
| Turret Menu | 3-24 |
| Auto Price Menu | 3-25 |
| Discount Menu | 3-27 |
| Diagnostics Menu | 3-29 |
| Default Menu | 3-30 |
| Blind Operator Feature | 3-30 |

SECTION 4

TROUBLESHOOTING

| | |
|--------------------------------------|-----|
| Check List | 4-1 |
| Turret Motor Errors | 4-2 |
| Coin Mech Problems | 4-2 |
| Initial Power Up | 4-3 |
| Power-Up Initialization | 4-3 |
| Refrigeration System | 4-3 |
| Compressor Circuit Description | 4-4 |
| Table 4-1 Component Resistance | 4-4 |
| Backup Refrigeration Unit | 4-5 |
| Backup Refrigeration Schematic | 4-5 |

| | |
|---|------|
| Refrigeration System Wiring | |
| Diagram (Domestic) | 4-6 |
| Refrigeration System Wiring | |
| Diagram (European) | 4-7 |
| Power Supply Indicator Lights | 4-8 |
| Troubleshooting Chart | |
| Error Messages | 4-10 |
| Troubleshooting Chart | |
| Problem / Solution | 4-12 |
| Troubleshooting Chart | |
| Refrigeration | 4-15 |
| System Schematic | 4-19 |
| Universal Control Board Schematic | 4-21 |
| Power Supply Schematic | 4-25 |
| Message Center Display Schematic | 4-29 |

SECTION 5

MAINTENANCE

| | |
|-------------------------------------|-----|
| Introduction | 5-1 |
| Adjustments | 5-1 |
| Delivery Door Switch | 5-1 |
| Lock Bar Switch | 5-1 |
| Trans-Motor Interlock Switch | 5-2 |
| Repair and Replacement | 5-2 |
| Checking Refrigeration System | 5-2 |
| Turret Removal | 5-3 |
| Delivery Door Removal | 5-3 |
| Cleaning | 5-3 |

SECTION 6

PARTS CATALOG

| | |
|---|------|
| Table of Contents | 6-1 |
| Main Door and Trim Panels | 6-4 |
| Main Door (Exterior) | 6-6 |
| Message Center | 6-8 |
| Main Door (Interior) | 6-10 |
| Lower Main Door Components | 6-12 |
| Coin Mech Compartment | 6-14 |
| Door Assembly - Coin Mech Compartment | 6-16 |
| Delivery Door Panel Assembly | 6-18 |
| Cabinet Final Assembly | 6-20 |
| Power Supply Assembly | 6-24 |
| Main Panel Switch | 6-26 |
| Turret Drive Motor Assembly | 6-28 |
| Turret Components - Bottom | 6-30 |
| Turret Drive and Roller | 6-31 |
| Lock Bar Solenoid | 6-32 |
| Refrigeration Unit | 6-33 |
| Universal Control Board | 6-35 |
| Power Supply Circuit Board Assembly | 6-38 |
| Harness List | 6-41 |
| European Part Numbers | 6-42 |
| Hardware List | 6-43 |

SPECIFICATIONS:

548 Showcase Merchandiser

GENERAL

| | |
|--|------------|
| Depth | 35 5/8 in. |
| Width | 41 in. |
| Height | 72 in. |
| Net Weight | 790 lb. |
| Shipping Weight | 840 lb. |
| Maximum Location Ambient Temperature | 110° F |

POWER REQUIREMENTS

| | | |
|-----------------|---------|-------------|
| Voltage | 120 VAC | 220/240 VAC |
| Current | 16 AMPS | 10 AMPS |
| Frequency | 60 HZ | 50/60 HZ |

VEND CAPACITY

| | |
|------------------------------------|-----------------------|
| Total Items | 154 MAX. |
| Delivery Doors | 11 |
| Delivery Door Dimensions (Nominal) | |
| 9 Doors | 4 in Height |
| 2 Doors | 5 in Height |
| 11 Doors | 6 or 9 in. Width |
| Compartment Depth (Nominal) | 9 1/4 in. Depth |
| Shelf Configurations Available: | |
| Over/Under | 14 Products Per Shelf |
| Plain | 7 Products Per Shelf |
| Vertical Split | 14 Products Per Shelf |
| Food Compartment | |
| Operating Temperatures | 38° ± 4° F |

COIN MECHANISMS

| | |
|--------------------------|-----------------|
| 120V Models-12 or 15 Pin | |
| MARS | TRC - 6000 |
| COINCO | 9300L |
| 24 V Models-15 Pin Only | |
| MARS | TRC - 6010 - XV |
| COINCO | 9302LF |

CAUTION !

Do not use 24 volt Coin Mech with 12 pin plugs! This will result in permanent damage to the Coin Mech and/or vending machine.

REFRIGERATION SYSTEM

| | <u>120 V</u> | <u>220/240 V</u> |
|---------------------------|-------------------|-------------------|
| Type | 3/4 HP Air Cooled | 3/4 HP Air Cooled |
| Charge | R404a (18oz.) | R404a (510 Grams) |
| Operating Pressures | @ 75° F | @ 24° C |
| High Side : | 200 - 240 psig | 1440-1579 KPA |
| Low Side : | 23 - 25 psig | 137-151 KPA |
| Test Pressures: | 300 psig | |

CAUTION !

This system is charged with R404a Refrigerant.

HOW TO USE THIS MANUAL

This manual contains six sections. The front section contains a table of contents, power requirements and operating specifications. Described below is a brief outline of the numbered sections and the information discussed there.

SECTION 1 - DESCRIPTION - Section 1 contains a general introduction to the 548 Showcase Merchandiser. It provides descriptions of the major components and features of the machine and a listing of point of sale messages. Before attempting to unpack or install this vendor, read and familiarize yourself with this section and Section 2 - Installation.

SECTION 2 - INSTALLATION - Section 2 contains unpacking and setup instructions. This section describes how to initialize the machine, load the coin mechanism and perform a pre-operation check. Use this section to install and check out the vendor.

SECTION 3 - PROGRAM OPERATION - Section 3 contains detailed programming information and instructions necessary to perform all of the service mode operations. This section will explain how to enable the functions available on this machine. It provides a detailed explanation of MIS features and operations.

SECTION 4 - TROUBLESHOOTING - Section 4 contains troubleshooting procedures, troubleshooting charts, schematics and wiring diagrams for the entire vendor Main Controller and Refrigeration Unit are also located in this section. Use this section in conjunction with the information in Section 5 - Maintenance, to isolate and repair vendor malfunctions.

SECTION 5 - MAINTENANCE - Section 5 contains instructions for cleaning, adjusting, repairing and replacing components on the 648 Merchandiser. Adjustment, repair and replacement procedures should be performed only as required. Isolate equipment trouble using the information and diagrams in Section 4 before attempting to make adjustments or replace parts. Illustrations detailing the sold out switch actuator adjustment are located in this chapter.

SECTION 6 - PARTS CATALOG - Section 6 contains a view of each assembly with part and section called out. Part numbers under a four digit assembly number are indented to the right if they are shipped as a group when ordering the assembly number. If they are not indented they must be ordered individually.

COIN MECH. CHART

| ROWE VENDING MACHINE COIN MECH USAGE | | | | | | | | | | | | | |
|---|--------|-----|--------|-----|--------|--------|-----|--------|-----------|-----|-------------|-------------|------|
| Coin Acceptors | 406 | | | | 425 | | | | 448 E2 | 505 | 548/ 648 | 550/ 650 | 5900 |
| Coinco | 6 PUMP | | 6 PUMP | | W.A.D. | 6 PUMP | | W.A.D. | | | | | |
| | WOBA | WBA | WOBA | WBA | | WOBA | WBA | | | | | | |
| 9300S Single Price \$12.75 Max 120 VAC | X | | X | | | X | | | | | | | |
| 9340S Single Price \$12.75 Max 120 VAC | X | X | X | X | | X | X | | | | | | |
| 9360S Single Price \$12.75 Max 120 VAC | X | X | X | X | | X | X | | | | | | |
| S75-9800B-907 Single Price \$3.15 Max 120 VAC | X | | X | | | X | | | | | | | |
| S75-9400B-977 Single Price \$1.15 Max 120 VAC | X | | X | | | X | | | | | | | |
| F300E-9210 Four Price \$3.15 Max 120 VAC | 3 | 3 | 3 | 3 | | X | X | | | | | | |
| F300-9400 Four Price \$3.15 Max 120 VAC | X | | X | | | X | | | | | | | |
| S300-9410 Single Price \$3.15 Max 120 VAC | X | X | X | X | | X | X | | | | | | |
| 9300L Microtech 110 VPDC | | | | | X | | | X | X | X | X | X | X |
| 9302LF Microtech 24 VPDC 15 Pin Con. | | | | | | | | | | X | X | X | X |
| MARS | | | | | | | | | | | | | |
| Cashflow | | | | | | | | | | X | X | X | X |
| TRC6010XV Microtech 24 VPDC 15 Pin Con. | | | | | | | | | | X | X | X | X |
| MC5000 Microtech 117 VPDC \$12.75 Max | | | | | X | | | X | X | X | X | X | X |
| TRC6000 Microtech 117 VPDC \$12.75 Max | | | | | X | | | X | X | X | X | X | X |
| TRC6200 120V Single Price \$5.55 Max | X | X | X | X | | X | X | | | | | | |
| TRC6200H 120V Single Price \$5.55 Max | 1 | 4 | | 4 | | 4 | | | | | | | |
| TRC6800 120V Single Price \$10.00 Max | X | X | X | X | | X | X | | | | | | |
| TRC6800H 120V Single Price \$10.00 Max | | 4 | | 4 | | 4 | | | | | | | |
| MC5802 Single Price 115 VAC | X | X | X | X | | X | X | | | | | | |
| MC5807 Single Price 115 VAC | X | X | X | X | | X | X | | | | | | |
| MC5920 Four Price 115 VAC \$5.35 Max | X | 2 | X | 2 | | X | 2 | | | | | | |
| MC5920H Four Price 115 VAC \$5.35 Max | | | | | | | | | | | | | |
| MS1600 European 24 VAC 50 Hz | | | | | | | | | X | X | X | X | X |
| MS1700 European Tropicalized 24 VAC 50 Hz | | | | | | | | | X | X | X | X | X |
| MS1900 European 24 VAC 50 Hz | | | | | | | | | X | X | X | X | X |
| NRI | | | | | | | | | | | | | |
| G-25.4400 European 24 VAC 50 Hz | | | | | | | | | X | X | X | X | X |
| Azkoyen | | | | | | | | | | | | | |
| AN-200 | | | | | | | | | | X | | | X |

1= Use with 408-6027 Kit 2= Remove R35 from MC5920 AH when using CBA - 2 B.A. (Also Needs 425-1856 harness)
 3= Needs four price kit 4= B.A. Compatible

548 Features

MESSAGE CENTER

The 548's message center has a 20 character vacuum fluorescent display that can scroll up to 300 characters. It can be programmed to display a custom message or the time and date.

By pressing the following key combinations on the Message Center, the following information can be displayed:

HOT KEYS

| | |
|-------------|-------------------------|
| <BLANK> <C> | Inside temp. Celsius |
| <BLANK> <D> | Date and time |
| <BLANK> <F> | Inside temp. Fahrenheit |
| <BLANK> <H> | Health control status |
| <BLANK> <I> | Machine ID number |
| <BLANK> <K> | *Security Code |

*Note: Operates in service mode only.

EASYKEY™ MENU SYSTEM

Programming is simple using four programming keys to navigate through the menus to program the machine:

| | |
|-------|--------|
| <UP> | <DOWN> |
| <SET> | <NEXT> |

REAL TIME CLOCK

Keeps track of start and stop times for options and when faults occur.

TURRET LOCKOUT

Up to 6 large sections (12 small sections) can be reserved until a specified time.

RANDOM FREE VEND

The customer can win a free product. Variable odds (1:50 to 1:3000).

DISCOUNTS

Up to three discount schedules can be offered. Each with their own start and stop times by date and time.

PROGRAMMABLE COIN LOADING

Coins can be loaded through the top or side of coin the mech.

MIS(MANAGEMENT INFORMATION SYSTEM)

Keeps track of:

- Sales by shelf
- Sales by product codes
- Number of free vends
- Value of free vends
- Number of random free vends
- Value of random free vends
- Number of discount #1 sales
- Value of discount #1 sales
- Number of discount #2 sales
- Value of discount #2 sales
- Number of discount #3 sales
- Value of discount #3 sales
- Number of schedule #1 vends
- Number of schedule #2 vends
- Number of schedule #3 vends

MIS keeps accurate inventory of money in the Cash Box, Coin Mech, Bill Stacker and Card Credit. It provides resettable and non-resettable sales data.

MULTIVIEW

Rotates the turret 3 sections, every 3 minutes at programmable start and stop times.

NEW TURRET DESIGN

- Can be rotated in either direction.
- Can be easily removed in one piece.
- Removable blower screen at vend door.
- Dynamic non-mechanical brake.

COIN MECHANISM

Can use either 110VDC (12 or 15 pin) or 24VDC (15 pin) Coin mechanisms

NOTE: See Coin Mech Chart page viii.

REFRIGERATION SYSTEM

- Unit easily removable in one piece
- Uses environmental friendly R404a refrigerant.
- Compressor start delayed to prolong compressor lifespan.

OTHER FEATURES

- Debit Card Reader Capability
- Hard Copy Printout Capability
- FIFO or SHOPPER Capability
- Four Shelves for Inside Storage
- Blind Operator Mode

This page intentionally left blank.

This document is available free of
charge to our customers
www.automaticproducts.com

Section 1: DESCRIPTION

INTRODUCTION

The 548 Showcase Merchandiser has a maximum capacity of 154 items. It is capable of three level pricing controlled by its own Real Time Clock. Sections of the turret can be locked out of availability until a preset time. The Universal Control Board (UCB) permits individual programming to vend in either the FIFO (First In/First Out) mode or the Shopper mode. For setting prices please refer to page 3-2.

The message center uses point of sale messages to help customers make purchases, while the UCB collects and accumulates MIS (Management Information Systems).

The UCB stores error messages in the event of a system malfunction, which will help to quickly isolate the problem and return the vendor to service. Refer to page 1-5 for Point of Sale messages and page 4-10 for error messages respectively.

MAJOR COMPONENTS

Universal Control Board

The UCB controls and monitors the vendor's performance. Further, it regulates its temperature, stores times and prices, records error messages, accumulates cash totals and interfaces with the message center.

Message Center

Partially seen from the outside of the unit, the message center houses the vacuum fluorescent display, **TURRET ROTATION** keys, **SELECTION** keys, and the **SET, NEXT, UP,** and **DOWN** keys used in programming this unit. These programming keys are used to access the EasyKey™ Menu System described in the Section 3.

Coin Mechanisms

The 548 Showcase Merchandiser provides a 15 Pin Domestic Coin Mechanism Socket. This allows the use of 120 Volt 'Dumb Mechs' with both 12 and 15 pin plugs, and a 24 Volt 'Dumb Mech' with the 15 pin plug.

NOTE:

Do NOT use a 24 Volt Mech with the 12 pin, 120 volt plug. If used, damage to Coin Mech and vendor will occur. (See page viii - Coin Mech Chart - for appropriate Coin Mech use.)

Main Power Switch Assembly

This assembly is located in the bottom left corner of the cabinet. It houses the Main Power ON/OFF switch, along with a switch which opens the refrigeration circuit to prevent frost build up. It also contains two circuit breakers to protect the vendor from a power overload. The vend interlock switch that opens the vend circuit when the door is ajar is located on the inside of the main door near the cash box.

Service Switch

This switch is located in along the edge, on the hinge side, of the Main Door. It is a momentary rocker switch that can be used to single step or continuously rotate the Turret when cleaning and replenishing product.

Shelf Assemblies

A four shelf storage rack is located along the right wall of the cabinet. This rack is intended to store nonperishable precooled products to be used at the next servicing.

Turret

The Turret can be rotated in both directions and programmed to lock out sections until a preset time. Refer to page 3 - 24. At each subsequent power up, the turret will automatically rotate one full revolution to assure proper relationship to the UCB's logic setting.

Electronic Digital Thermometer

The electronic digital thermometer is located on the inside of the main door. This probe is used to monitor the temperature of the cabinet interior for the Universal Control Board, which in turn, controls the unit's Temperature and the Health Control feature.

To read the interior cabinet temperature, press the <BLANK> key on the selection keyboard, followed by the <F> key. The display will show the temperature in degrees Fahrenheit, or press <BLANK> then <C> for the temperature in Celsius.

Health Control

After opening and closing the main door, the compressor has 30 minutes in which to bring the vending compartment temperature down to 45° F.

To display the amount of time remaining in the pulldown period, press the <BLANK> key and then the <H> key. "HEALTH DELAY XX MINS" will appear on the message center.

After the 30 minute pull down period expires, if the <BLANK> key is depressed and then the <H> key is depressed "HEALTH CONTROL ON" will appear on the message center. This indicates that the temperature inside the vending compartment, is being monitored. If the temperature inside the vending compartment rises above 45° F for a one minute period, the machine will go out of service.

To display the time and date the machine went out of service press the <BLANK> key and then the <H> key. "OFF 'TIME' 'DATE'" will be displayed on the message center, where "TIME" and "DATE" are the time and date when the machine went out of service due to a health control error.

To reset a "HEALTH TIME EXPIRED" error, clear the errors and open and shut the main door. Depress the <BLANK> key and then depress the <H> key to display "HEALTH DELAY XX MINS" on the message center. If the message center still displays "OFF 'TIME' 'DATE'", then there is a problem with the main door switch.

REFRIGERATION

Electrical (Domestic)

The self contained refrigeration system is designed to slide in and out of the vendor as one complete assembly. A normal 3 pin AC power cord supplies power to the Compressor, Evaporator Blower, and the Condenser Fan. The evaporator blower runs continuously while AC power is applied, regardless of the temperature inside the machine. The condenser fan runs only when the compressor is running. The compressor and condenser fan are controlled by a relay (P/N 938-8001) located on the power supply chassis.

When the main door is opened, the refrigeration interlock power switch opens, turning off power to the evaporator blower, the compressor and condenser fan. When the main door is closed, the evaporator blower will start immediately but there is a one minute delay before power is applied to the compressor and condenser fan. This delay is used to attain maximum life from the compressor by avoiding rapid ON/OFF cycling.

Health Control Sensor

There is only one temperature probe for both the refrigeration control and the health control. The temperature probe is located on the door at the bottom of the left hand fluorescent lamp reflector.

NOTE:

The compressor control processing runs independently of the health control processing. If the machine goes out of service, the compressor control processing will continue to operate.

The temperature sensor is a solid state temperature measuring device (P/N 548-01818). This temperature sensor converts temperature into a proportional voltage. The Universal Controller Board tracks and displays the temperature of the air and controls the refrigeration and health status. If the temperature probe is disconnected, the temperature reading will go up to 96° F regardless of the true air temperature. Whenever the temperature probe reading is above 80° F the refrigeration control is transferred to the manual backup system. When the temperature falls below 80°, the UCB will again take control of the refrigeration unit. This prevents the machine from becoming too warm if the temperature probe fails. To display the temperature inside the vending compartment, depress the <BLANK> key and then the <F> key. The display will read, "TEMPERATURE = XX F" (BLANK + C = Temperature Celsius)

Compressor Algorithm

The compressor will turn on one minute after closing the main door and will stay on for 20 minutes or until the temperature inside the vending compartment falls below 36° F. If the compressor does not bring the temperature below 36° F within the 20 minute period then the compressor will turn off for a period of two minutes. After two minutes have expired, the compressor will turn back on for another 20 minute period. This 20 minute on and two (2) minute off cycle will continue until the temperature in the vending compartment falls below 36° F.

Once the temperature inside the vending compartment falls below 36° F, the compressor will turn off.

After three minutes, if the temperature inside the vending compartment reaches 40° F the compressor will turn on for at least 80 seconds, but no more than 30 minutes. When the temperature inside the vending compartment falls below 36° F the compressor will turn off for at least 3 minutes.

Vend Cards

The 548 is capable of interfacing with a debit card system without any setup or modifications. The new NAMA MC5000 Interface for Debit Card Systems has been implemented and it is not backward compatible to the old NAMA standards.

If an old NAMA standard debit card system is used, the debit card system will not receive all of the credit signals being used by the 548 and card credit may be lost.

If a Debittek brand debit card system is being used, it is recommended that the system be configured in "Coins to Card Mode". If the "No Coins to Card Mode" is used, there may be discrepancies in the coin MIS displays when credit exists prior to insertion of the card.

The 548 will recognize and support 1 cent credit even though the machine prices are settable in 5 cent increments. Credit acceptance will be disabled once the maximum current machine price is exceeded. Vend card sales information is displayed in the MIS menu and printout. If a vend card is inserted in service mode, the credit transferred can only be viewed in the diagnostic menu. The coin payouts are disabled while vend card credit is established.

Printer

A serial printer may be connected to the UCB to print the MIS information displayed in the MIS Menu. A "PRINTER NOT READY" message will be displayed if a print MIS is attempted and the printer is not connected or off-line.

548 Communication Setting

Baud Rate = 9600 (default)

1200 & 2400 (programmable)

Data Bits = 8

Parity = No

Stop Bit = One

Messages Prior to Credit

SORRY-OUT OF SERVICE This message will appear whenever there is an error condition logged by the software. The display lamps will be out when one or more error conditions exist.

INSERT MONEY This message appears when a Bill Validator is configured and there is sufficient change in the Coin Mechanism.

EXACT CHANGE PLEASE This message appears whenever there is insufficient change in the Coin Mechanism. Users can buy with an over credit and the machine will try to make the correct change.

COINS ONLY PLEASE This message appears only when a Bill Validator is not configured and there is sufficient change.

MAKE FREE SELECTION Machine is in Free Vend. No money is required.

HEALTH CONTROL ON 30 Minute Health Delay expired. Depress <BLANK> Key and then the <H> Key.

ONE MOMENT PLEASE Machine is locating zero position.

11.59PM SUN 12/31/91 Depress <BLANK> Key and then <D> Key. Time - Day of Week - Date.

TEMPERATURE 36° F Depress the <BLANK> Key and then <F> Key. Displays current temperature of Vend Compartment.

TEMPERATURE 4° C Depress the <BLANK> Key and then <C> Key. Displays current temperature of Vend Compartment.

HEALTH DELAY 30 MINS Time remaining during 30 Minute Health Delay. Depress the <BLANK> Key and then the <H> Key.

MAIN DOOR IS OPEN Attempt is made to turn the turret with the keypad when the main door is open.

CLOSE ALL VEND DOORS This message appears when an attempt is made to rotate the turret and the UCB side of the motor interlock switch is open and a delivery door switch is not closed.

Credit Messages

CREDIT - \$ 1.25 Purchaser's current credit, validated by the Coin Mech and/or Bill Validator.

Selection Messages

ITEM IS NOT AT DOOR Turret is positioned for 1/2 compartment vend, when attempting to open a full compartment.

INSUFFICIENT CREDIT Not enough credit to purchase item.

MUST MAKE SELECTION <Coin Return> depressed when vendor has Forced Vend Option in use.

PRESS SELECTOR KEY J Vend attempted at FIFO Door. User must press the <Selector> key corresponding to the desired shelf.

SHELF J NOW READY FIFO Shelf has been positioned to vend.

DOOR D IS OPEN Delivery Door D is open.

YOU ARE A WINNER Random Free Vend Option is on. Customer receives Free Vend.

CAN'T MAKE CHANGE Prohibit Overbuy Option is on, correct change unavailable for vend selected. Forced Vend must be OFF.

ITEM PREVIOUSLY SOLD This message appears when a vend door with a previously purchased compartment is attempted to be opened.

RESERVED SECTION Turret Delay is in use. Can not vend from that section.

OPEN On Column Display when a vend door is open.

Vend Completed

THANK YOU Transaction has been completed successfully.

SOLD On Column Display when an item has been sold.

POINT OF SALES MESSAGES

ENGLISH

THANK YOU
 CREDIT - \$ 1.25
 COINS ONLY PLEASE
 INSERT MONEY
 OPEN
 EXACT CHANGE PLEASE
 KEY D
 SHELF J NOW READY
 MAKE FREE SELECTION
 HEALTH CONTROL ON
 ITEM PREVIOUSLY SOLD
 INSUFFICIENT CREDIT
 MUST MAKE SELECTION
 SORRY-OUT OF SERVICE
 RESERVED SECTION
 ITEM IS NOT AT DOOR
 YOU ARE A WINNER
 CAN'T MAKE CHANGE
 ONE MOMENT PLEASE
 11.59PM SUN 12/31/91
 11.59PM MON 12/31/91
 11.59PM TUE 12/31/91
 11.59PM WED 12/31/91
 11.59PM THU 12/31/91
 11.59PM FRI 12/31/91
 11.59PM SAT 12/31/91
 TEMPERATURE 36 F
 TEMPERATURE 7 C
 HEALTH DELAY 30 MINS
 SOLD
 MACHINE I.D. _____
 CLOSE ALL VEND DOORS

FRENCH

MERCI
 CREDIT - \$ 1.25
 PIECES SEULEMENT SVP
 INTRODUIRE PIECES
 PORTE OUVERTE
 MONTANT EXACT SVP
 APPUYER LA TOUCHE D
 PLATEAU J PRET
 SELECTION GRATUITE
 CONTROLE EN COURS
 ARTICLE VENDU
 MONNAIE INSUFFISANTE
 DOIT FAIRE UN CHOIX
 HORS SERVICE
 SECTION RESERVEE
 ARTICLE NON-ALIGNE
 VOUS AVEZ GAGNE
 CAN'T MAKE CHANGE
 UN MOMENT SVP
 11.59PM DIM 12/31/91
 11.59PM LUN 12/31/91
 11.59PM MAR 12/31/91
 11.59PM MER 12/31/91
 11.59PM JEU 12/31/91
 11.59PM VEN 12/31/91
 11.59PM SAM 12/31/91
 TEMPERATURE 36 F
 TEMPERATURE 7 C
 DELAI DE TEMP 30 MIN
 SOLD
 MACHINE I.D. _____
 CLOSE ALL VEND DOORS

SPANISH

GRACIAS
 CREDITO - \$ 1.25
 SOLO MONEDAS
 INTRODUCZA MONEDAS
 DOOR A IS
 PUERTA A ABIERTA
 CAMBIO EXACTO
 PRESS SELECTOR
 SELECCIONE TECLA D
 REPISA J PREPARADA
 SELECCIONE
 REVISANDO PRODUCTO
 ARTICULOS AGOTADOS
 CREDITO INSUFICIENTE
 SELECCIONE OPCION
 FUERA DE SERVICIO
 PRODUCTO ELEGIDO
 ARTICULO AGOTADO
 HAS GANADO
 CAN'T MAKE CHANGE
 UN MOMENTO POR FAVOR
 11.59PM DOM 12/31/91
 11.59PM LUN 12/31/91
 11.59PM MAR 12/31/91
 11.59PM MIE 12/31/91
 11.59PM JUE 12/31/91
 11.59PM VIE 12/31/91
 11.59PM SAB 12/31/91
 TEMPERATURA 36 F
 TEMPERATURA 7 C
 REVISION 30 MINS
 SOLD
 MACHINE I.D. _____
 CLOSE ALL VEND DOORS

TABLE 1 - 1 POINT OF SALES MESSAGE

This page intentionally left blank.

This document is available free of
charge to our customers
www.automaticproducts.com

Section 2

INSTALLATION

INTRODUCTION

This section contains instructions for unpacking the 548 Showcase Merchandiser and installing it on location. Installation is quick and easily accomplished.

UNPACKING INSTRUCTIONS

The merchandiser is shipped in one carton with all major assemblies in place, ready for installation. The shipping carton should be opened carefully to prevent the merchandiser from being scratched or damaged. Inspect the exterior and interior of the cabinet for evidence of damage. If evidence of damage exists, notify the delivering carrier at once to examine the vendor regardless of the external condition of the carton. Under U.S. regulations, damage claims must be collected from the consignee. Do not return shipping-damaged merchandise until after your claim has been established. Once your claim has been established, damaged merchandise may be returned to an authorized distributor for repair. The invoice for repair charges may then be collected from the carrier. Do not destroy packing material or boxes until the carrier's agent has examined them.

CAUTION !

Pushing or sliding the merchandiser (by hand) on the floor can result in considerable damage to the machine and/or personal injury. Always use appropriate material handling equipment and adequate protective padding to protect the merchandiser.

SET-UP INSTRUCTIONS

1. Place the unit in a well ventilated location with a minimum of **SIX INCHES** between unit and back wall.
2. Remove all tape and packing material from cabinet.
3. The unit must be leveled. Perform level adjustment by using the following illustration:




Figure 2-1. Level Adjustment

CAUTION !

If unit is not leveled correctly the refrigerator evaporator may freeze up, causing unit shutdown.

4. Ensure that circuit breakers are firmly in place and that fluorescent lamps are secure in their sockets.
5. Ensure that the Main Power Switch is in the OFF position.
6. Plug the line cord into a dedicated, positively grounded receptacle, capable of delivering the required power as stated on page vi.

7. Install a recommended Coin Mech (See Specification Sheet page viii).
 - a) Check coin chute alignment.
 - b) Check coin return lever operation.
 - c) Adjust if necessary.
8. Install letter labels (Enclosed in plastic envelope) in the corresponding vend doors. ("A" on top to "K" on bottom).
9. Check and insure that all electrical connections are seated properly, especially at the circuit boards.
10. Turn the Main Power Switch ON.
11. Upon Power-up the following sequence of displays should occur:
 - A. The Lock Bar Solenoid energizes.
 - B. The Price Display Boards shall read from top to bottom:

| | | |
|----------------|------------|----------|
| a. "11111" | b. "99.95" | "599.95" |
| "22222" | "99.95" | "599.95" |
| "33333" | "99.95" | "599.95" |
| "44444" | "99.95" | "599.95" |
| "55555" | "99.95" | "599.95" |
| "66666" (THEN) | "99.95" OR | "599.95" |
| "77777" | "99.95" | "599.95" |
| "99999" | "99.95" | "599.95" |
| "AAAAA" | "99.95" | "599.95" |
| "BBBBB" | "99.95" | "599.95" |
| "CCCC" | "99.95" | "599.95" |
 - C. The Message Center should display:
 - a. "KEYPAD-DISPLAY VX.X"
(X.X = latest version of Message Center Display)
{Then}
 - b. "ROWE 648/548 VX.X"
(X.X = latest revision EPROM on UCB)
{Then}
 - c. "SERVICE MENU" or "ERROR MESSAGE"
12. Check that all Fluorescent lamps are illuminated.
13. Ensure that the following LEDs on the Universal Control Board are illuminated:
 - +5 VDC (Logic Voltage)
 - VFD (Vacuum Fluorescent Display Voltage)

VSRC (Device Source voltage)
TEST *Blinking* (Control Board Operating Heartbeat)

14. Check the service switch operation by rotating the Turret one full rotation. (See page 6 - 10 (item 11) of Parts Section for location of switch)
15. Perform a full initialization to program the machine to factory default settings.
 - A. In the Service Mode depress the <NEXT> key until the Message Center displays "DEFAULT MENU"
 - B. Depress the <SET> key;
"MACHINE INIT - NONE" displays.
 - C. Depress the <UP> key until
"MACHINE INIT - FULL" displays.
 - D. Depress the <SET> key;
"TURN UNTIL ZERO POS" or
"SERVICE MENU" displays.
 - E. With the outside transport switch, rotate the turret until "SERVICE MENU" displays.

NOTE:

Main Door must be closed or "Main Door is Open" Message will be generated.

COIN MECH LOADING

16. This unit must be set up for total cash accountability to operate correctly. You may use one of these two methods to load the coin mechanism.
 - A. In the Service Mode (with coin mech door open) all coin denominations may be loaded through the top flight deck of the coin mech.
 - B. Programming Method: You must keep count and load all the coin denominations through the side loading tubes. In the coin level of the MIS MENU section, the inserted amounts can be keyed into the program. (Refer to page 3-10 of the MIS MENU Section, and perform detailed instructions in the Set Coin Tubes section).

PRE-OPERATION CHECK

1. Perform the Basic Program Set-up routine located in the Service Mode Operation, Section - 3.
2. Close all machine doors. "INSERT MONEY" or other vending mode messages should display if all parameters were set correctly and no errors exist (See Point of Sale Messages Table 1-1, page 1-5.)
3. Rotate the turret one full revolution to the left with transport rocker switch.
4. Rotate the turret one full revolution to the right with transport rocker switch.
5. Insert Coins (5¢, 10¢, 25¢) and make a vend.
6. Check and verify the coin return amount.
7. (If equipped with Bill Acceptor) Insert bill(s). Make a vend.
8. Check and verify the coin return amount.
9. Test vend each door, rotating the turret one space between vends.
10. Close and latch the main door to reset electronic count down timer. The vendor now has 30 minutes to reach 45° F (7.2° C) interior cabinet temperature. The vending circuit will be interrupted by the UCB if temperature requirement is not satisfied, placing the machine out of service.
11. Unit is now ready.

NOTE:

On initial start up in high ambient temperature it is normal to experience a shut down after the first 30 minutes. Simply open the coin mech door and clear the "Health Time Expired" error. Open and then re-shut the main door (This resets 30 minute health timer). No further shutdown should occur.

This document is available free of
charge to our customers
www.automaticproducts.com

This page intentionally left blank.

This document is available free of
charge to our customers
www.automaticproducts.com

Section 3

SERVICE MODE

INTRODUCTION

The Universal Control Board uses a menu driven interface to configure the merchandiser, choose from available options, access the MIS information, and troubleshoot the merchandiser. Opening the Coin Mech compartment door will automatically bring you into the **SERVICE MENU**. There are nine menu items which are available for programming and/or servicing the 548 Showcase Merchandiser. The message center has ten service keys, four of which are used to access the Easy Key™ Menu System. All messages that will appear on the display will be shown in all upper case letters enclosed with quotation marks.

To move from one menu to another menu, press the **<NEXT>** key. To scroll through the options within that menu, press the **<SET>** key. The first attribute of each option will be displayed. The value or setting of that option may be changed by using the **<UP>** or **<DOWN>** keys. Pressing the **<SET>** key will move to the next option within the menu. Pressing the **<NEXT>** key will move to the next menu.




Figure 3-1. Keypad

The **<5¢>**, **<10¢>**, and **<25¢>** keys are used to dispense coins from the coin mech. The **<\$1>** key will be used for the dollar coin when it becomes available.

ERROR MESSAGES

When the coin mech door is opened, the display will show ***** SERVICE MENU *****. If there were any error conditions recorded since the last time the door was opened, the display will show **"ERROR MESSAGES"**.

Press the **<SET>** key and the display will list the error(s) that have been recorded. Continue pressing the **<SET>** key to see all the errors. After all error messages have been shown, the display will show **"CLEAR ERRORS - NO"**. Use the **<UP>** or **<DOWN>** key to select **"YES"** or **"NO"**, then press the **<SET>** key.

If you select **"NO"**, the errors will still be logged the next time the coin mech door is opened.

Note:

If you select **"YES"**, all the error messages will be cleared. This does not correct any problems. It only clears the messages.

If you do not want to see each individual error message press the key to display **"CLEAR ERRORS - NO"**. Use the **<UP>** or **<DOWN>** keys to select **"YES"**, then press the **<SET>** key.

BLIND OPERATOR FEATURE

When dip switch #1 is set to **ON** the Price Menu key (indicated by the asterisk in the illustration at left) becomes a price menu key for blind operators.

BASIC PROGRAM SET-UP

This section covers a quick set-up for customers not interested in utilizing special features.

Open the Coin Mech Door to display and enter the "SERVICE MODE".

If "ERROR MESSAGE" displays, refer to the Troubleshooting Section of the manual for correction.

1. SET PRICE

Perform the following:

| <u>Depress Key</u> | <u>Displays</u> |
|----------------------|-----------------------------|
| A. <NEXT> | "PRICE MENU" |
| B. <SET> | "PRICE SCHED - 1 ACTIVE" |
| C. <SET> | "SET PRICE 1 - \$X.XX" |
| D. <UP> or <DOWN> | "SET PRICE 1 - \$X.50" |

Upon setting the desired price (Step D), click applicable vend door(s) to the right for this price setting. Repeat Step D for different prices.

2. COIN MECH

Load all coin denominations through the coin mech's top flight deck

NOTE:

If coins are loaded through the side tubes, there is no accountability unless the amount inserted is programmed in the MIS Menu.

3. SET SHELF SIZE

Perform following:

| <u>Depress Key</u> | <u>Displays</u> |
|--------------------|---------------------|
| A. <SET> | "SHELF SIZE - HALF" |
| B. <UP> or <DOWN> | "SHELF SIZE - FULL" |

Toggle (Step B) to desired shelf size and click applicable vend door(s) to the right.

4. SET SHOPPER/FIRST IN FIRST OUT

Perform following:

| <u>Depress Key</u> | <u>Displays</u> |
|----------------------|--------------------|
| A. <SET> | "VENDMODE - SHOP" |
| B. <Up> or <DOWN> | "VEND MODE - FIFO" |

Toggle (Step B) to desired shelf mode and click applicable vend door(s) to the right.

5. ENABLE BILL ACCEPTOR

If unit is equipped with Bill Acceptor, perform the following:

- A. Depress the <NEXT> key until "OPTION MENU" displays.
- B. Depress the <SET> key until "BILL ACCEPTOR OFF" displays.
- C. Depress <UP> or <DOWN> key to toggle Bill Acceptor Enable to OFF or ON, then press the <SET> key.
- D. Depress the <NEXT> key to exit OPTION MENU.
- E. Repeat steps B, C & D for \$1 Accept / Reject, \$2 Accept/Reject and \$5 Accept / Reject.

Security Code

If the Security Code feature is enabled, the display will show "SECURITY CODE - ****". Use the <UP> or <DOWN> keys to display the first character in the security code. When the first character is displayed, press the <SET> key. Continue this procedure for the remaining characters in the security code.

After entering the correct security code and pressing the <SET> key for the last character, the message center will display, "FULL ACCESS GRANTED".

If the security code is unknown the operator may press the <NEXT> key which will enable him to have access to the PRICE, MIS, AUTO PRICE, and DIAGNOSTIC menus.

NOTE:

If the operator has enabled the security feature, selected menus will not be accessible without entering the security code. DO NOT lose the security code.

Sold Out Check Feature

This feature is used to verify if a compartment has been refilled with tampered food.

When the coin mech door is opened, the display will show "*** SERVICE MENU ***". When the sold out feature is enabled and if no error conditions exist, the display will show "CHECK SOLD OUT DOORS".

The price display at each door will show "SOLD" if that compartment should be empty. Open the compartment door and the display will show "NONE". If there is product in a compartment that says "SOLD", discard it. Rotate the turret with the outside transport switch and check the compartments that say "SOLD". Once all the compartments have been cleared, the machine will automatically go into the Service Mode and the display will show "***SERVICE MENU***".

FILLING THE TURRET

Since the Universal Control Board keeps track of the compartment states, it needs to be notified when the machine is being filled. If the main door is opened and the service switch is turned on without touching any message center keys in between, the 548 assumes it is being filled and a "FILLING MACHINE" message is displayed and all compartment solds are reset. If any key is touched before turning on the service switch, the machine assumes it is being serviced, and a "SERVICING MACHINE" message is displayed and the compartment states remain unchanged.

Exact Change Mode

The 548 is in exact change mode and "EXACT CHANGE ONLY" will be displayed on the message center, unless one of the following conditions is met.

1. 2 dimes and a nickel, or 5 nickels are in the coin tubes, then "COINS ONLY PLEASE" will be displayed on the message center (when B/A is disabled).
2. If the bill acceptor is enabled and 3 quarters 2 dimes and a nickel, or 3 quarters and 5 nickels are in the coin tubes, then "INSERT MONEY" will be displayed on the message center.

Table 3-1
Factory Default Settings

The following program settings are factory default settings and will be obtained upon operation of the DEFAULT MENU / INITIALIZE FULL routine.

| | | | | | |
|---|-----------------|---------------------------|----------------|--------------------------|---------------|
| Price Menu | | RAND VENDS - | 0 | Discount Menu | |
| PRICE SCHED - 1 | ACTIVE | FREE VENDS - | 0 | SET DISCOUNT 1 - | NO |
| (Price Display all 99.95) | | DISC 1 VENDS - | 0 | SET DISCOUNT 2 - | NO |
| PRICE SCHED - 2 | ACTIVE | DISC 2 VENDS - | 0 | SET DISCOUNT 3 - | NO |
| (Price Display .05 through .55) | | DISC 3 VENDS - | 0 | | |
| PRICE SCHED - 3 | ACTIVE | MIS CLEAR COUNT - | X * | Diagnostic Menu | |
| (Price Display .60 through 1.10) | | POWER LOSSES - | NO * | HEALTH TEST - | NO |
| SET PRICE 1 - \$.50 (5¢ to \$99.95) | | PRICE CHANGED - | NO * | CARD CREDIT - | \$.00 |
| SHELF SIZE - HALF (FULL) | | OUT OF SERVICE - | NO * | ZERO POS - | NO |
| SET VEND MODE - SHOP (FIFO) | | TIME OVER HEALTH - | NO | | |
| MULTICODES - OFF (ON) | | MAX TEMPERATURE - | NO | Default Menu | |
| SET PROD CODE - 0 (0 to 99) | | MIN TEMPERATURE - | NO | MACHINE INIT - | NONE |
| | | CLOCK CHANGES - | 0 * | PRINT BAUD RATE - | 9600 |
| MIS Menu | | Options Menu | | | |
| SET COIN TUBES - | NONE | MULTIVIEW - | OFF | | |
| BILL ACPT EMPTY - | NO | FORCED VEND - | OFF | | |
| CASH BOX EMPTY - | NO | BILL ACCEPTOR - | OFF | | |
| PRINT MIS DATA - | NO | SOLD OUT CHECK - | OFF | | |
| CLEAR MIS DATA - | NO | FREE VEND - | OFF | | |
| SALES (R) - | \$.00 | RNDM FREE VEND - | OFF | | |
| SALES (N) - | \$.00 * | DISPLAY TIME - | OFF | | |
| BAG TOTAL - | \$.00 | SET MACHINE ID - | NO | | |
| CASHBOX - | \$.00 | SECURITY CODE - | OFF | | |
| CARD SALES - | \$.00 | SET MESSAGE - | OFF | | |
| BILL TOTALS - | \$.00 | COLUMN DISPLAY - | SOLD | | |
| ONES - | \$.00 | PROHIBIT VENDING - | NO | | |
| TWOS - | \$.00 | LANGUAGE - | ENGLISH | | |
| FIVES - \$.00 | | PROHIBIT OVERBUY - | NO | | |
| COIN TOTALS - | \$.00 | | | | |
| \$1 COINS - | \$.00 | Clock Menu * | | | |
| QUARTERS - | \$.00 | DATE - | 1/17/92 | | |
| DIMES - | \$.00 | SET TIME - | NO | | |
| NICKELS - | \$.00 | TIME - | 11.32 | | |
| RAND VEND - | \$.00 | SET TIME - | NO | | |
| FREE VEND - | \$.00 | | | | |
| DISC 1 - | \$.00 | Turret Menu | | | |
| DISC 2 - | \$.00 | TURRET DELAY - | OFF | | |
| DISC 3 - | \$.00 | | | | |
| TOTAL VENDS - | 0 | Auto Price Menu | | | |
| SCHED 1 VENDS - | 0 | ENABLE SCHED 2 - | NO | | |
| SCHED 2 VENDS - | 0 | ENABLE SCHED 3 - | NO | | |
| SCHED 3 VENDS - | 0 | | | | |
| VENDS PER SHELF - | 0 | | | | |

* Denotes Non-resettable Values

QUICK-REFERENCE GUIDE

To check inside cabinet temperature (without opening Coin Mech. Door):

1. Press <Blank> key on keypad
2. Press <F> key (F is for Fahrenheit)
3. Press <C> key (C is for Celsius)

To check Health Control time delay (without opening Coin Mech. Door):

1. Press <Blank> key on keypad
2. Press <H> key (H is for Health Control Status and for time left in initial 30 min. health delay check).

To check Machine ID:

1. Press <Blank> then I key.

To set prices:

1. Press <NEXT> key on Message Center to reach (PRICE MENU)
2. Press <SET> key to reach (PRICE 0.00)
3. Change price shown by using <up> or <down> keys
4. Toggle doors you wish to change to that price

To payout change from coin mech (manually):

1. Press coin switch (5¢, 10¢, or 25¢) on Message center.

To extract MIS data:

1. Press <NEXT> key on Message Center to reach (MIS MENU)
2. Press <SET> to advance through each MIS category
3. (SALES <N>) is Non-resettable (cumulative) cash meter
4. (SALES <R>) is Resettable cash meter

To print MIS data:

1. Connect compatible printer using proper interface cable
2. Press <NEXT> key on Message Center to reach (MIS MENU)
3. Press <SET> key to reach (PRINT MIS DATA -NO)
4. Press <UP> or <DOWN> key to select (PRINT MIS DATA -YES)
5. Press <SET> key to automatically print data

To clear SOLD-out doors:

1. Open Main Cabinet Door. (Do NOT press keys on Message Center)
2. Rotate turret with Service Switch, not outside switches

To clear an error (if lights go out, but prices remain lit):

1. Error descriptions will appear when the coin mech door is opened
2. Press the <SET> key each time an error message displays.
3. (CLEAR ERRORS -NO) will appear
4. Press <UP> or <DOWN> key to select (CLEAR ERRORS -YES)
5. Press <SET> key again, to clear the error

NOTE:

If the recorded error is a Health Time Expired error, the error must be cleared, then the main door must be opened and shut again to reset. It will now have 30 minutes to cool down.

If the recorded error is a Main Door Open error, make sure the main door is securely latched before attempting to clear the error.

Table 3-2. Miscellaneous Information

| | |
|---|--------------|
| Maximum price: | \$99.95 |
| Number of price schedules: | 3 |
| Number of discounts: | 3 |
| Maximum product code: | 99 |
| Free vend odds range: | 50-3000 |
| Maximum scrollable message length: | 300 chars |
| Maximum fixed message length: | 20 chars |
| Maximum machine ID length: | 12 chars |
| Maximum security code length: | 4 chars |
| Multiview time period: | 3 minutes |
| Compressor turn on temperature: | 40 degrees F |
| Compressor turn off temperature: | 34 degrees F |
| Compressor minimum on time: | 80 seconds |
| Compressor minimum off time: | 3 minutes |
| Maximum health control temperature: | 45 degrees F |
| Maximum time over health control temperature: | 5 minutes |
| Health Control pull down delay: | 30 minutes |
| Health test delay time: | 20 seconds |




Figure 3-2. Mini Menu System




Figure 3-3. Service Mode Full Menu Flowchart

PRICE MENU

The **PRICE** menu contains the menu items used to set prices, shelf sizes, vending modes and product codes.

Price Sched

The purpose of **PRICE SCHED** is to select an active Price Schedule. (See **SET PRICE** section).

There are three Price Schedules that may be activated either manually or automatically by time and day. (See **AUTO PRICE MENU** section).

To select a price schedule:

- 1) Press the **<SET>** key until "PRICE SCHED-N ACTIVE" is displayed on the message center. (Where N = 1, 2, or 3.)
- 2) Use the **<UP>** or **<DOWN>** key to select schedule "1", "2", "3", or "AUTO N". The schedule that is selected will determine what prices the machine will use in vend operation.
- 3) If "AUTO" is selected, the active schedule number (N) is determined by the active **AUTOPRICE** times (See **AUTO PRICE MENU** section). (Times are displayed also). If no times have been set up or the **AUTOPRICE** schedules are disabled, Schedule 1 is used.

Set Price

The purpose of the **SET PRICE** option is to set each shelf to a specific price.

To set prices:

- 1) Press the **<SET>** key until "SET PRICE N-\$.XX" is displayed on the message center. (N = 1, 2, or 3, XX = .05 to 99.95).
- 2) Use the **<UP>** or **<DOWN>** key to select the desired price, then toggle the corresponding vend door to set the price. (Notice the column display will reflect the desired price for that shelf).

Shelf Size

The purpose of the **SHELF SIZE** option is to set a compartment to either "HALF" size or "FULL" size.

If the shelf sizes are set to "HALF", then there are 14 compartments to a shelf. If they are set to "FULL", then there are 7 compartments to a shelf. The default for all shelves is "HALF" size.

To set the size of a shelf:

- 1) Press the **<SET>** key until the message center displays "SHELF SIZE - HALF".
- 2) Use the **<UP>** or **<DOWN>** key to change the setting to either "HALF" or "FULL".
- 3) Toggle the door corresponding to the desired shelf and notice the column display will reflect the size configuration of the shelf. (i.e., "HALF" or "FULL").

Set Vend Mode

The purpose of the **SET VEND MODE** option is to set a shelf's vend mode to either "SHOP" or "FIFO" mode.

If a shelf is set to "FIFO" mode, the machine dispenses items in the order they were loaded. In other words, the First In is the First Out ("FIFO"). If this mode is to be implemented, it should be done after initialization, or after the shelves have been filled using the **SERVICE/FILLING SWITCH**, and before any vends have been made.

If the shelf is set to "SHOP" mode, the machine allows the customer to choose any product on a shelf provided that the compartment has not been sold. "SHOP" mode may be implemented at any time and is the default setting.

If "FIFO" mode is chosen, the machine will allow vends starting from the first compartment or zero position, incrementing up to compartment 14 if "HALF" size shelf, or compartment 7 if "FULL" size shelves.

NOTE:

If TURRET DELAY is active no shelves are allowed to be in "FIFO" mode. (See section TURRET DELAY).

To set "FIFO" or "SHOP" mode:

- 1) Press the <SET> key until the message center displays "SET VEND MODE - SHOP".
- 2) Use the <UP> or <DOWN> key to change the setting to either "FIFO" or "SHOP".
- 3) Toggle the door at the desired shelf and notice the column display will reflect the status of that shelf. (i.e., "FIFO" or "SHOP").

Multi Codes

The purpose of **MULTI CODES** is to set individual product codes for each shelf.

To set multicodes mode:

- 1) Press the <SET> key until the message center displays "MULTI CODES - OFF".
- 2) Use the <UP> or <DOWN> key to change the setting to either "ON" or "OFF".
- 3) Toggle the door at the desired shelf and notice the column display will reflect the status of that shelf. (i.e., "ON" or "OFF").

Set Product Code

The purpose of the **SET PROD CODE** is to set each shelf to a specific product code. (See **MULTI CODES** section).

To set product codes:

- 1) Press the <SET> key until the message center displays "SET PROD CODE - 0".
- 2) Use the <UP> or <DOWN> key to select the desired product code.
- 3) Toggle the door at the desired shelf and notice the column display will display the product code.
- 4) To set a different product code simply change the product code with the <UP> or <DOWN> keys and toggle any door to set the shelf to the new product code. The product codes range from 0 to 99.

NOTE:

Pressing the [NEXT] key at any time will advance to the following menu. All changes that have been set will automatically be saved.

MIS MENU

The MIS menu contains the menu items that are used to display and print the MIS data collected by the 548. This menu also contains items used to adjust the number of coins in the coin mech.

Set Coin Tubes

The purpose of the SET COIN TUBES option is empty the coin tubes or adjust the number of coins in the coin tubes.

Empty Tubes

- 1) *To empty the coin tubes:*
 - a) Press the <SET> key until "SET COIN TUBES - NONE" appears on the message center.
 - b) To empty the coin tubes completely, use the <UP> or <DOWN> keys until "SET COIN TUBES-EMPTY" is displayed on the message center.
 - c) Press the <SET> key.
 - d) To stop emptying coins, press any key.

NOTE:

The controller will dispense the number of coins recorded in the MIS coin count regardless of the physical coin count.

- 2) *To fill the coin tubes from the side of the coin mechanism:*
 - a) Use the <UP> or <DOWN> keys until "SET COIN TUBES - LOAD" is displayed on the message center.
 - b) Press the <SET> key.
- 3) Loading the coin tubes can also be performed by loading the coins through the top flight deck of the Coin Mech. at anytime during service mode.

\$1 Coins Added

- 1) "\$1 COINS ADDED - 0" appears on the message center.

- 2) Use the <UP> or <DOWN> keys to display the number of dollar coins that are being added through the side of the coin tube.
- 3) Press the <SET> key.

Quarters Added

- 1) "QUARTERS ADDED - 0" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display the number of quarters that are being added through the side of the coin tube.
- 3) Press the <SET> key.

Dimes Added

- 1) "DIMES ADDED - 0" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display the number of dimes that are being added through the side of the coin tube.
- 3) Press the <SET> key.

Nickels Added

- 1) "NICKELS ADDED - 0" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display the number of nickels that are being added through the side of the coin tube.
- 3) Press the <SET> key.

NOTE:

If the "EMPTY" option is used, the coin amounts that the coin mechanism delivers are recorded in the BAG TOTAL. (See BAG TOTAL section). If the "LOAD" option is used, the new coin totals will be reflected in the tube totals. (See COIN TOTAL, \$1 COINS, QUARTERS, DIMES, and NICKELS sections).

Bill Accept Empty

The purpose of **BILL ACCEPT EMPTY** is to clear the bill tallies after the bill stacker is emptied. The bill tallies are added to the **BAG TOTAL**.

To use the BILL ACCEPT EMPTY feature:

- 1) After the bill stacker is emptied, Press the <SET> key until "BILL ACCEPT EMPTY - NO" appears on the message center.
- 2) Use the <UP> or <DOWN> keys, display "YES" on the message center.
- 3) Press the <SET> key. (See **BAG TOTAL** section).

Cash Box Empty

The purpose of **CASH BOX EMPTY** is to clear the cash box tallies after it is emptied. The cash box tallies are added to the **BAG TOTAL**.

To use the CASH BOX EMPTY feature:

- 1) After the cash box is emptied, Press the <SET> key until "CASH BOX EMPTIED - NO" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display "YES" on the message center.
- 3) Press the <SET> key. (See **BAG TOTAL** section).

Print MIS

The **PRINT MIS** menu item sends the MIS data to the RS-232 port to be printed. The MIS menu data, software version, time and date, machine ID and audit number will be included.

NOTE:

To print MIS data use the Seiko DPU-411-21BU hand held printer and the CPC Vending printer harness. P/N 593-1800, available from CPC parts suppliers.

To send the MIS information:

- 1) Press the <SET> key until "PRINT MIS DATA - NO" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display "YES" on the message center.
- 3) Press the <SET> key.

Clear MIS Data

The purpose of the **CLEAR MIS DATA** function is to perform a MIS Reset, which will zero all totals except for the non-resettable information.

To clear the MIS information:

- 1) Press the <SET> key until "CLEAR MIS DATA - NO" appears on the message center.
- 2) Use the <UP> or <DOWN> keys, display "YES" on the message center.
- 3) Press the <SET> key. (See **MIS CLEAR COUNT** section).

Sales (R)

The purpose of **SALES (R)** is to display the total amount of sales that the machine has made since the last initialization or MIS Reset. "SALES (R)-\$.XX" will appear on the message center, where XX is the dollar amount. When the amount exceeds \$99999.95 it will restart at \$.00.

To display the resettable sales:

Press the <SET> key until "SALES (R)-\$.XX" appears on the message center. (Where XX is the dollar amount).

Sales (N)

The purpose of **SALES (N)** is to display the total amount of sales that the machine has made. It can never be reset. "SALES (N)-\$.XX" will appear on the message center, where XX is the dollar amount. When the amount exceeds \$99999.95 it will restart at \$.00.

To display the non-resettable sales:

Press the <SET> key until "SALES (N)-\$.XX" appears on the message center. (Where XX is the dollar amount).

Bag Total

The purpose of **BAG TOTAL** is to display the total amount of money that has been emptied from the bill acceptor and the coin box. When the amount exceeds \$99999.95 it will restart at \$.00.

To display the bag total:

Press the <SET> key until "BAG TOTAL-\$.XX" appears on the message center. (Where XX is the dollar amount).

Cash Box

The purpose of **CASH BOX** is to display the total amount of money in the cash box. When the amount exceeds \$99999.95 it will restart at \$.00.

To display the cash box total:

Press the <SET> key until "CASH BOX-\$XX" appears on the message center. (Where XX is the dollar amount).

Card Sales

The purpose of **CARD SALES** is to display the total amount of vend card sales. When the amount exceeds \$99999.95 it will restart at \$.00.

To display the card sales:

Press the <SET> key until "CARD SALES-\$ XX" appears on the message center. (Where XX is the dollar amount).

Bill Total

The purpose of **BILL TOTAL** is to display the total value of the bills held in the bill stacker. When the amount of bills exceeds 999 it will restart at \$.00.

To display the bill total:

Press the <SET> key until "BILL TOTAL-XX" appears on the message center. (Where XX is the dollar amount).

Ones

The purpose of **ONES** is to display the total number and value of one dollar bills held in the bill stacker. When the bills count exceeds 999 it will restart at 1.

To display the one dollar bill total:

Press the <SET> key until "ONES-N \$.XX" appears on the message center. (Where N is the number of bills and XX is the dollar amount).

Twos

The purpose of **TWOS** is to display the total number and value of two dollar bills held in the bill stacker. When the bill count exceeds 999 it will restart at 1.

To display the two dollar bill total:

Press the <SET> key until "TWOS-N \$.XX" appears on the message center. (Where N is the number of bills and XX is the dollar amount).

Fives

The purpose of **FIVES** is to display the total number and value of five dollar bills held in the bill stacker. When the bill count exceeds 999 it will restart at 1.

To display the five dollar bill total:

Press the <SET> key until "FIVES-N \$.XX" appears on the message center. (Where N is the number of bills and XX is the dollar amount).

Coin Total

The purpose of **COIN TOTAL** is to display the total value of the coins held in the coin tubes. When the value of the coins exceeds \$999.00 it will restart at \$.00.

To display the coin total:

Press the <SET> key until "COINS TOTAL-\$.XX" appears on the message center. (Where XX is the dollar amount).

\$1 Coins

The purpose of **\$1 COINS** is to display the total number and value of \$1 coins held in the coin mech tubes.

To display the \$1 coin total:

Press the <SET> key until "\$1 COINS-N \$.XX" appears on the message center. (Where N is the number of coins and XX is the dollar amount).

Quarters

The purpose of **QUARTERS** is to display the total number and value of quarters held in the coin mech tubes.

To display the quarter coin total:

Press the <SET> key until "QUARTERS-N \$.XX" appears on the message center. (Where N is the number of coins and XX is the dollar amount).

Dimes

The purpose of **DIMES** is to display the total number and value of dimes held in the coin mechanism tubes.

To display the dime coin total:

Press the <SET> key until "DIMES-N \$.XX" appears on the message center. (Where N is the number of coins and XX is the dollar amount).

Nickels

The purpose of **NICKELS** is to display the total number and value of nickels held in the coin mechanism tubes.

To display the nickels coin total:

Press the <SET> key until "NICKELS-N \$.XX" appears on the message center. (Where N is the number of coins and XX is the dollar amount).

Rand Vends-\$

The purpose of **RAND VENDS-\$** is to display the total monetary amount of random free vend sales that have occurred. When the number of random free vends exceeds 9999, random free vend value will restart at \$.00.

To display the random vend monetary total:

Press the <SET> key until "RAND VEND-\$.XX" appears on the message center. (Where XX is the dollar amount).

Free Vends-\$

The purpose of **FREE VENDS** is to display the total monetary amount of free vend sales that have occurred. When the number of free vends exceeds 9999, free vend value will restart at \$.00.

To display the free vend monetary total:

Press the <SET> key until "FREE VEND-\$.XX" appears on the message center. (Where XX is the dollar amount).

Disc 1- \$

The purpose of **DISC 1- \$** is to display the amount of money discounted from the scheduled prices while Discount 1 was active. When the number of Discount 1 exceeds 9999, the Discount 1 vend value will restart at \$.00.

To display the Discount 1 monetary total:

Press the <SET> key until "DISC 1 - \$.XX" appears on the message center. (Where XX is the dollar amount).

Disc 2 - \$

The purpose of **DISC 2 - \$** is to display the amount of money discounted from the scheduled prices while Discount 2 was active. When the number of Discount 2 exceeds 9999, the Discount 2 vend value will restart at \$.00.

To display the Discount 2 monetary total:

Press the <SET> key until "DISC 2 - \$.XX" appears on the message center. (Where XX is the dollar amount).

Disc 3 - \$

The purpose of **DISC 3 - \$** is to display the amount of money discounted from the scheduled prices while Discount 3 was active. When the number of Discount 3 exceeds 9999, the Discount 3 vend value will restart at \$.00.

To display the Discount 3 monetary total:

Press the <SET> key until "DISC 3 - \$.XX" appears on the message center. (Where XX is the dollar amount).

Total Vends

The purpose of **TOTAL VENDS** is to display the total number of vends that have occurred. When the amount of total vends exceeds 9999 it will restart at 1.

To display the total number of vends:

Press the <SET> key until "TOTAL VENDS - N" appears on the message center. (Where N is the number of vends.)

Sched 1 Vends

The purpose of **SCHED 1 VENDS** is to display the total number of vends that have occurred while Schedule 1 prices were active. Schedule 1 is the default schedule. When the amount of Schedule 1 vends exceeds 9999 it will restart at 1.

To display the number of vends during Price Schedule 1:

Press the <SET> key until "SCHED 1 VENDS - N" appears on the message center. (Where N is the number of vends).

Sched 2 Vends

The purpose of **SCHED 2 VENDS** is to display the total number of vends that have occurred while Schedule 2 prices were active. When the amount of Schedule 2 vends exceeds 9999 it will restart at 1.

To display the number of vends during Price Schedule 2:

Press the <SET> key until "SCHED 2 VENDS - N" appears on the message center. (Where N is the number of vends).

Sched 3 Vends

The purpose of **SCHED 3 VENDS** is to display the total number of vends that have occurred while Schedule 3 prices were active. When the amount of Schedule 3 vends exceeds 9999 it will restart at 1.

To display the number of vends during Price Schedule 3:

Press the <SET> key until "SCHED 3 VENDS - N" appears on the message center. (Where N is the number of vends).

Vends per Shelf

The purpose of **VENDS PER SHELF** is to display on the column display the total number of vends that have occurred on each of the shelves. When the number of vends per shelf exceeds 9999 it will restart at 1.

To display the vends per shelf:

Press the <SET> key until "VENDS PER SHELF" appears on the message center. The number of vends per shelf will appear in the price displays.

Random Vends

The purpose of **RANDOM VENDS** is to display the total number of random free vends that have occurred (See RNDM FREE VEND Section). When the amount of random vends exceeds 9999 it will restart at 1.

To display the total number of random free vends:

Press the <SET> key until "RANDOM VENDS - N" appears on the message center. (Where N is the number of vends).

Free Vends

The purpose of **FREE VENDS** is to display the total number of free vends that have occurred. When the amount of free vends exceeds 9999 it will restart at 1.

To display the total number of free vends:

Press the <SET> key until "FREE VENDS - N" appears on the message center. (Where N is the number of vends).

Disc 1 Vends

The purpose of **DISC 1 VENDS** is to display the total number of discounted vends while Discount 1 was active. When the amount of Discount 1 vends exceeds 9999 it will restart at 1.

To display the total number of vends while discount 1 was active:

Press the <SET> key until "DISC 1 VENDS - N" appears on the message center. (Where N is the number of vends).

Disc 2 Vends

The purpose of **DISC 2 VENDS** is to display the total number of discounted vends while Discount 2 was active. When the amount of Discount 2 vends exceeds 9999 it will restart at 1.

To display the total number of vends while discount 2 was active:

Press the <SET> key until "DISC 2 VENDS - N" appears on the message center. (Where N is the number of vends).

Disc 3 Vends

The purpose of **DISC 3 VENDS** is to display the total number of discounted vends while Discount 3 was active. When the amount of Discount 3 vends exceeds 9999 it will restart at 1.

To display the total number of vends while discount 3 was active:

Press the <SET> key until "DISC 3 VENDS - N" appears on the message center. (Where N is the number of vends).

MIS Clear Count

The purpose of **MIS CLEAR COUNT** is to display the number of times that the MIS has been cleared via the MIS CLEAR menu item or "FULL" machine initialization. (See CLEAR MIS DATA and MACHINE INIT sections). This data is non-resettable.

To display the number of times the MIS has been cleared:

Press the <SET> key until "MIS CLEAR COUNT - N" appears on the message center. (Where N is the number of clears).

Power Losses

The purpose of **POWER LOSSES** is to display the last time and date that the machine lost power. If the machine has never lost power, "NOT APPLICABLE" will be displayed. This data is non-resettable.

To display the last time the machine lost power:

- 1) Press the <SET> key until "POWERLOSSES - NO" appears on the message center.
- 2) By using the <UP> or <DOWN> keys, displaying "YES" on the message center and Pressing the <SET> key, will display the last time, day and date the power to the machine had been off.

Price Changed

The purpose of **PRICE CHANGED** is to display the last time and date that a price was changed. If the prices have never been changed, then "NOT APPLICABLE" will be displayed. This data is non-resettable.

To display the last time a price changed:

- 1) Press the <SET> key until "PRICE CHANGED - NO" appears on the message center.
- 2) By using the <UP> or <DOWN> keys, displaying "YES" on the message center and Pressing the <SET> key, will display the last time, day and date a price had changed. (To set or change prices see SET PRICE section).

Out of Service

The purpose of **OUT OF SERVICE** is to display the last time and date that the machine went out of service. If the machine has never gone out of service then "NOT APPLICABLE" will be displayed. This data is non-resettable.

To display the last time the machine went out of service:

- 1) Press the <SET> key until "OUT OF SERVICE - NO" appears on the message center.
- 2) By using the <UP> or <DOWN> keys, displaying "YES" on the message center and Pressing the <SET> key, will display the last time, day and date the machine went out of service.

Time Over Health

The purpose of **TIME OVER HEALTH** is to display the amount of time the refrigerated compartment has been over the health temperature. If the compartment has not exceeded the health temperature after the Pull Down period then "NOT APPLICABLE" will be displayed, otherwise the length of time the compartment has been over the health temperature and the maximum temperature that the compartment has reached will be displayed.

To display Time Over Health:

- 1) Press the <SET> key until "TIME OVER HEALTH - NO" appears on the message center.
- 2) Use the or <UP> or <DOWN> keys to display "YES"
- 3) Press the <SET> key.
- 4) "HH.MM.SS XX F MAX" will appear on the message center. If the temperature in the refrigerated compartment did not exceed the

maximum health temperature then "NOT APPLICABLE" will appear on the message center. (Where HH is hours, MM is minutes, SS is seconds, and XX is degrees Fahrenheit).

Max Temperature

The purpose of **MAX TEMPERATURE** is to allow the operator to display the maximum temperature that the refrigerated compartment has achieved after the machine has reached the pull down temperature.

The message center will display the maximum temperature along with the date and time the maximum temperature was achieved.

If the temperature inside the refrigerated compartment has not reached the pull down temperature then "MIN TEMP NOT REACHED" will appear on the message center.

To display the maximum temperature:

- 1) Press the <SET> key until "MAX TEMPERATURE-NO" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display "YES".
- 3) Press the <SET> key. "TTF MM/DD/YY HH.NNXXM" will appear on the message center. (Where TT is the maximum temperature in Fahrenheit, MM is the month, DD is the day, YY is the year, HH is the hour, NN is the minute, and XM is either AM or PM). If the temperature inside the refrigerated compartment has not reached the pull down temperature then "MIN TEMP NOT REACHED" will appear on the message center.

Min Temperature

The purpose of **MIN TEMPERATURE** is to allow the operator to display the minimum temperature that the refrigerated compartment has achieved after the machine has reached the pull down temperature.

The message center will display the minimum temperature along with the date and time the minimum temperature was achieved.

If the temperature inside the refrigerated compartment has not reached the pull down temperature then "MIN TEMP NOT REACHED" will appear on the message center.

To display the minimum temperature:

- 1) Press the <SET> key until "MIN TEMPERATURE-NO" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display "YES".
- 3) Press the <SET> key. "TTF MM/DD/YY HH.NNXXM" will appear on the message center. (Where TT is the minimum temperature in Fahrenheit, MM is the month, DD is the day, YY is the year, HH is the hour, NN is the minute, and XM is either for AM or PM.) If the temperature inside the refrigerated compartment has not reached the pull down temperature, "MIN TEMP NOT REACHED" will appear on the message center.

Clock Changes

The purpose of **CLOCK CHANGES** is to display the number of times the clock has been changed. If the clock has never been changed then "NOT APPLICABLE" will be displayed. This data is non-resettable.

To display the number of times the clock has been changed:

- 1) Press the <SET> key until "CLOCK CHANGES - NO" appears on the message center.
- 2) By using the <UP> or <DOWN> keys, displaying "YES" on the message center and pressing the <SET> key, "TIMES CHANGED - N" will appear. (Where N is the number of times the clock has changed. To change or set the date, time, or day see section SET DATE, SET TIME, or SET DAY).

NOTE:

Pressing the <NEXT> key at any time will advance to the following menu. All changes that have been set will automatically be saved.

OPTIONS MENU

The **OPTIONS** menu contains the menu items used to enable/disable the Multiview, Forced Vend, Sold Out Check, Free Vend, Random Free Vend, Display Time, Column Display and Prohibit Overbuy options. In this menu the Bill Acceptor can be enabled, the display language selected and the Security Code, Machine ID and Point of Sale message programmed.

Multiview

The purpose of **MULTIVIEW** is to rotate the turret three sections every three minutes. The turret will not rotate if there is credit pending in the machine or if a vend or turret rotation had occurred 15 seconds prior to the scheduled **MULTIVIEW** rotation.

If **MULTIVIEW** is selected, the active time period must be specified. A time period is described by start and end times between and including the start and end days.

For example: If **MULTIVIEW** should be in effect from 9:00AM to 5:00PM on Monday through Friday, set the **START TIME** to "9:00AM", the **STOP TIME** to 5:00PM, the **START DAY** to "MONDAY" and the **END DAY** to "FRIDAY".

To describe a complete 24 hour time period, set the **START TIME** to some time, 9:00AM for example. Then set the **END TIME** to 1 minute less than that time, 8:59AM in this case.

To describe a complete week time period, set the **START DAY** to some day, Monday for example. Then set the **END DAY** to the previous day, Sunday in this case.

*To use the **MULTIVIEW** option:*

- 1) Press the <SET> key until "MULTIVIEW - OFF" appears on the message center. Use the <UP> or <DOWN> keys to display "ON".
- 2) Press the <SET> key.

START TIME

"START TIME - HH:MM XM" will appear on the message center. This is the time of day that **MULTIVIEW** will become active. To continue, Press the <SET> key.

Set Start Time

"SET START TIME - NO" appears on the message center.

To set the start time:

- 1) Use the <UP> or <DOWN> keys to display "YES" on the message center.
- 2) Press the <SET> key.

Set Hours

"SET HOURS - HH XM" will appear on the message center.

To change the hour:

- 1) Use the \uparrow or \downarrow keys to display the correct hour.
- 2) Press the <SET> key.

Set Mins

"SET MINS - MM" will appear on the message center.

To change the minutes:

- 1) Use the \uparrow or \downarrow keys to display the correct minutes.
- 2) Press the <SET> key.

STOP TIME

"STOP TIME - HH.MM XM" will appear on the message center. This shows the time of day that **MULTIVIEW** will become inactive. To continue, Press the <SET> key.

Set Stop Time

"SET STOP TIME - NO" appears on the message center.

To set the stop time:

- 1) Use the \uparrow or \downarrow keys to display "YES" on the message center
- 2) Press the <SET> key.

Set Hours

"SET HOURS - HH XM" will appear on the message center.

To change the hour:

- 1) Use the \uparrow or \downarrow keys to display the correct hour.
- 2) Press the <SET> key.

Set Mins

"SET MINS - MM" will appear on the message center.

To change the minutes:

- 1) Use the <UP> or <DOWN> keys to display the correct minutes
- 2) Press the <SET> key.

START DAY

"START DAY-WWWDAY" will appear on the message center. This shows the day of the week that **MULTIVIEW** will become active. To continue, Press the <SET> key.

Set Start Day

"SET START DAY-NO" appears on the message center.

To set the start day:

- 1) Use the <UP> or <DOWN> keys to display "YES" on the message center.
- 2) Press the <SET> key.

Set Day

"SET DAY - WWWDAY" will appear on the message center.

To change the day:

- 1) Use the <UP> or <DOWN> keys to display the day.
- 2) Press the <SET> key.

END DAY

"END DAY-WWWDAY" will appear on the message center. This shows the day of the week that **MULTIVIEW** will become inactive. To continue, Press the <SET> key.

Set End Day

"SET END DAY-NO" appears on the message center.

To set the end day:

- 1) Use the <UP> or <DOWN> keys to display "YES" on the message center.
- 2) Press the <SET> key.

Set Day

"SET DAY - WWWDAY" will appear on the message center.

To change the day:

- 1) Use the <UP> or <DOWN> keys to display the day.
- 2) Press the <SET> key.

NOTE:

HH is hours, MM is minutes, XM is AM or PM, and WWW is the day of the week, i.e. SUN, MON, TUES, etc.)

Forced Vend

The purpose of **FORCED VEND** is to prevent the 548 from being used as a change machine. If credit is established in vend mode and the coin return is Pressed, "MUST MAKE SELECTION" is displayed if the **FORCED VEND** option is active. **FORCED VEND - OFF** is the default.

To set the FORCED VEND option:

- 1) Press the <SET> key until "FORCED VEND - OFF" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display "ON".
- 3) Press the <SET> key.

Bill Acceptor

The purpose of **BILL ACCEPTOR** is to enable the bill acceptor and the type of bills that the bill acceptor will accept.

To enable the bill acceptor:

- 1) Press the <SET> key until "BILL ACCEPTOR - OFF" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display "ON".
- 3) Press the <SET> key.

\$1 Bills

"\$1 BILLS - REJECT" will appear on the message center.

To accept one dollar bills:

- 1) Use the <UP> or <DOWN> keys to display "ACCEPT".
- 2) Press the <SET> key.

\$2 Bills

"\$2 BILLS - REJECT" will appear on the message center.

To accept two dollar bills:

- 1) Use the <UP> or <DOWN> keys to display "ACCEPT".
- 2) Press the <SET> key.

\$5 Bills

"\$5 BILLS - REJECT" will appear on the message center.

To accept five dollar bills:

- 1) Use the <UP> or <DOWN> keys to display "ACCEPT".
- 2) Press the <SET> key.

Sold Out Check

The purpose of **SOLD OUT CHECK** is to assist in the detection of possible product tampering. When this option is active, "SOLD" will be indicated on the column display for each compartment selected and "CHECK SOLD OUT DOORS" will appear on the message center at the start of the service menu.

For each compartment that displays a "SOLD" message on the column display, the door should be opened. Any product found in a sold compartment should be discarded. The column display will change to "NONE". When all the "SOLD" compartments have been toggled to "NONE", the column display will display the current prices and the message center will display "**** SERVICE MENU ****".

After filling the machine and closing the main door, "SET FIRST EMPTY" will be displayed. The turret should be turned to the first empty compartment on each shelf (starting from Section 1) and the door toggled. The compartments from that Section to Section 7 will be set to "NOT FILLED". Any shelf not set will be considered completely full once the <SET> key has been pressed.

To use the **SOLD OUT CHECK** option:

- 1) Press the <SET> key until "SOLD OUT CHECK OFF" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display "ON".
- 3) Press the <SET> Free Vend

The purpose of **FREE VEND** is to put the machine in free vend mode. When this option is active, the column display will show .00, and "MAKE FREE SELECTION" will be displayed in Vend Mode unless a point of sale message is invoked. (See **SET MESSAGE** section).

To use the **FREE VEND** option:

- 1) Press the <SET> key until "FREE VEND - OFF" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display "ON".
- 3) Press the <SET> key.

Random Free Vend

The purpose of **RNDM FREE VEND** is to randomly give a free vend. The occurrence of a free vend can be set from 1 in 50 to 1 in 3000. When a random free vend occurs, the vend price will be returned and the message center will display "YOU ARE A WINNER".

To use the **RNDM FREE VEND** option:

- 1) Press the <SET> key until "RNDM FREE VEND - OFF" appears on the message center.
- 2) Use the <UP> or <DOWN> arrow keys to display "ON".
- 3) Press the <SET> key.

Odds

"ODDS - 1 IN N" will appear on the message center.

To increment or decrement the odds:

- 1) Use the <UP> or <DOWN> keys.
- 2) Press the <SET> key. (N = 50 to 3000.)

Display Time

The purpose of **DISPLAY TIME** is to display on the message center during vend mode the time, day and date in vend mode providing that no point of sale message is active, the machine is not **OUT OF SERVICE**, and the machine is not in **EXACT CHANGE MODE**.

To use the **DISPLAY TIME** option:

- 1) Press the <SET> key until "DISPLAY TIME - OFF" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display "ON".
- 3) Press the <SET> key.

Set Machine ID

The purpose of **SET MACHINE ID** is to set a machine ID of up to 12 letters, numbers, or characters.

To set the **MACHINE ID**:

- 1) Press the <SET> key until "SET MACHINE ID - NO" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display "YES".
- 3) Press the <SET> key.
- 4) "MACH ID- _____" will appear on the screen.
- 5) Use the <UP> or <DOWN> keys to change the character that is being displayed.
- 6) When the desired character is displayed press the <SET> key.
- 7) The flashing " ^ " character signifies the current character.
- 8) If less than 12 characters, use the end bracket "] " to signify the end of message routine.
- 9) When all the characters in the ID are set or an end bracket character is used, the message center will again display "SET MACHINE ID - NO".
- 10) Press the <SET> key for the next menu item.

NOTE:

The machine ID can be displayed temporarily by Pressing the black <BLANK> key and then the <I> key on the key pad at any time.

Security Code

The purpose of the **SECURITY CODE** option, is to prevent access to certain features of the 548.

If the security code option is active, the only menus that would be accessible without the correct security code are: **PRICE, MIS, AUTOPRICE, and DIAGNOSTICS.**

When the security code option is active, "SECURITY CODE - _ _ _ _" will be displayed in the Service Mode after clearing all error messages (if applicable) and "CHECK SOLD OUT DOORS" (if applicable) appears.

The operator must then enter the security code. If the code is correct, "FULL ACCESS GRANTED" will be temporarily displayed and all the service menus are available. If the code is incorrect, only the menus listed above will be available.

To set the SECURITY CODE:

- 1) Press the <SET> key until "SECURITY CODE - OFF" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display "ON"
- 3) Press the <SET> key. "EDIT SEC CODE - NO" appears on the message center.
- 4) Use the <UP> or <DOWN> arrow keys to display "YES" and Press the <SET> key.
- 5) "SECURITY CODE _ _ _ _" will appear on the screen.
- 6) Use the <UP> or <DOWN> keys to change the character that is being displayed.
- 7) When the desired character is displayed Press the <SET> key.
- 8) The flashing "^" character signifies the current character. If less than 4 characters use the end bracket "]" to signify the end of message routine.
- 9) When all the characters in the security code are set or an end bracket character is used, the message center will again display "EDIT SEC CODE - NO".
- 10) Depress the <SET> key for the next menu item.

Set Message

The **SET MESSAGE** option is used to set a user definable Point of Sale Message.

The Point of Sale Message may be a fixed length message, which can be up to 20 characters long or a scrolling message, which can be up to 300 characters long. Either type of message will be displayed on the message center provided that the machine is in Vend Mode, not **OUT OF SERVICE**, and not in **EXACT CHANGE MODE.**

To set the Point of Sale Message:

- 1) Press the <SET> key until "SET MESSAGE - NO" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display "FIXED" or "SCROLL"
- 3) Press the <SET> key.
- 4) "EDIT MESSAGE - NO" will appear on the Message Center.
- 5) Use the <UP> or <DOWN> keys to display "YES".
- 6) Press the <SET> key. " _ _ _ _ _" will appear on the screen.
- 7) Use the <UP> or <DOWN> keys to change the character that is being displayed.
- 8) When the desired character is displayed Press the <SET> key.
- 9) The flashing " ^ " character signifies the current character. The end bracket "] " signifies the end of message character.
- 10) When all the characters in the ID are set or an end bracket character is used, the message center will again display "SET MESSAGE - NO".
- 11) Depress the <SET> key for the next menu item.

Column Display

The purpose of **COLUMN DISPLAY** is to eliminate the "Sold" messages on the column display when a compartment has been sold.

If "COLUMN DISPLAY-PRICE" is selected, the column will continue to display the price of each sold compartment. If "COLUMN DISPLAY-SOLD" is set, then "Sold" will be displayed on the column for each sold compartment. In either case, each compartment can only be sold one time. "ITEM PREVIOUSLY SOLD" will be displayed on the message center when attempting to open a sold compartment.

To set the column display after a vend:

- 1) Press the <SET> key until "COLUMN DISPLAY-SOLD" is displayed on the message center.
- 2) Use the <UP> or <DOWN> keys to display "PRICE".
- 3) Press the <SET> key for the price to be displayed after a vend, otherwise Press the <SET> key for the next menu item. (The default is "SOLD").

Prohibit Vending

The purpose of **PROHIBIT VENDING** is to allow the operator to put the machine **OUT OF SERVICE** without an error. When the service door is closed, the machine will be out of service, but there will be no error messages shown when service mode is entered.

To set the machine out of order:

- 1) Press the <SET> key until "PROHIBIT VENDING-NO" is displayed on the message center.
- 2) Use the <UP> or <DOWN> arrow keys to display "YES".
- 3) Press the <SET> key.

Language

The purpose of **LANGUAGE** is to allow the operator to display the vend message in either **ENGLISH**, **FRENCH**, or **SPANISH**. The default language is English.

To set the vend messages to a language:

- 1) Press the <SET> key until "LANGUAGE - ENGLISH" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display either "ENGLISH", "FRENCH", or "SPANISH"
- 3) Press the <SET> key.

Prohibit Overbuy

The purpose of **PROHIBIT OVERBUY** is to not allow an attempted buy when the correct change is unavailable in the coin tubes. Forced Vend option must be OFF to enable this feature.

To set the PROHIBIT OVERBUY option:

- 1) Press the <SET> key until "PROHIBIT OVERBUY-NO" is displayed on the message center.
- 2) Use the <UP> or <DOWN> keys to display "YES"
- 3) Press the <SET> key.

NOTE:

Pressing the [NEXT] key at any time will advance to the following menu. All changes that have been set will automatically be saved.

CLOCK MENU

The **CLOCK** menu contains the menu items that set the internal clock. Depress the black <BLANK> key on the key pad and then the <D> key to temporarily display the time, date and day of week.

DATE

"DATE - MM/DD/YY" will appear on the message center. This shows the current date. To continue, press the <SET> key.

Set Date

"SET DATE - NO" appears on the message center.

To change the date:

- 1) Use the <UP> or <DOWN> keys to display "YES" on the message center.
- 2) Press the <SET> key.

Set Day of Month

"SET DAY OF MONTH - DD" will appear on the message center. To change the day of the month:

- 1) Use the <UP> or <DOWN> keys to display the day of the month.
- 2) Press the <SET> key.

Set Month

"SET MONTH - MM" will appear on the message center.

To change the month:

- 1) Use the <UP> or <DOWN> keys to display the correct month
- 2) Press the <SET> key.

Set Year

"SET YEAR - YY" will appear on the message center.

To change the year:

- 1) Use the <UP> or <DOWN> keys to display the correct year.
- 2) Press the <SET> key.

TIME

"TIME - HH.MM XM WWW"* will appear on the message center. This is the current time. To continue, press the <SET> key.

Set Time

"SET TIME - NO" appears on the message center.

To change the time:

- 1) Use the <UP> or <DOWN> keys to display "YES" on the message center.
- 2) Press the <SET> key.

Set Hours

"SET HOURS - HH XM" will appear on the message center.

To change the hour:

- 1) Use the <UP> or <DOWN> keys to display the correct hour.
- 2) Press the <SET> key.

Set Mins

"SET MINS - MM" will appear on the message center.

To change the minutes:

- 1) Use the <UP> or <DOWN> keys to display the correct minutes.
- 2) Press the <SET> key.

Set Day

"SET DAY - WWWDAY" will appear on the message center.

To change the day:

- 1) Use the <UP> or <DOWN> keys to display the day.
- 2) Press the <SET> key.

(* HH is hours, MM is minutes, XM is AM or PM, and WWW is the day of the week, i.e. SUN, MON, TUES, etc.)

TURRET MENU

The **TURRET** menu contains the menu items used to reserve turret sections in the machine for vending at a later time.

TURRET DELAY

The purpose of **TURRET DELAY** is to prohibit vending in certain sections of the turret. Sections 2-7 may be reserved until some later time.

If **TURRET DELAY** is active and the turret is rotated into a reserved section, the machine will continue to rotate into the first vendible section, the message center will display "RESERVED SECTION" and the column display will show "—" in place of the prices.

When the delay end time has been reached, the delay is disabled until the machine is refilled. Turret delay is active for only 24 hours. It must be reset every 24 hours.

NOTE:

To make **TURRET DELAY** active, no shelves can be in "FIFO" mode. (See section SET VEND. MODE)

*To use the **TURRET DELAY** option:*

- 1) Press the <SET> key until "TURRET DELAY - OFF" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display "ON"
- 3) Press the <SET> key.

Delay Sections

"DELAY SECTIONS N - 7" will appear on the message center, where N is the starting "locked out" section, that is reserved for later vending.

- 1) Use the <UP> or <DOWN> keys to display the desired starting reserved turret section.
- 2) Press the <SET> key.

Stop Time

"STOP TIME - HH.MM XM" will appear on the message center. This is the time of day that the turret delay will end. To continue, press the <SET> key.

Set Stop Time

"SET STOP TIME - NO" appears on the message center.

To change stop time:

- 1) Use the <UP> or <DOWN> keys to display "YES" on the message center.
- 2) Press the <SET> key.

Set Hours

"SET HOURS - HH XM" will appear on the message center.

To change the hour:

- 1) Use the <UP> or <DOWN> keys to display the correct hour.
- 2) Press the <SET> key.

Set Mins

"SET MINS - MM" will appear on the message center.

To change the minutes:

- 1) Use the <UP> or <DOWN> keys to display the correct minutes
- 2) Press the <SET> key.

NOTE:

Pressing the [NEXT] key at any time will advance to the following menu. All changes that have been set will automatically be saved.

AUTO PRICE MENU

The **AUTO PRICE** menu contains the menu items that set the time periods during which the different price schedules will become active when **AUTO PRICE** is enabled.

A time period is described by start and end times between and including the start and end days. For example if price schedule 2 should be in effect from 9:00AM to 5:00PM on Monday through Friday, set the **START TIME** to 9:00AM, the **STOPTIME** to 5:00PM, the **START DAY** to **MONDAY** and the **END DAY** to **FRIDAY**.

To describe a complete 24 hour time period, set the **START TIME** to some time, 9:00AM for example. Then set the **END TIME** to 1 minute less than that time, 8:59AM in this case.

To describe a complete week time period, set the **START DAY** to some day, Monday for example. Then set the **END DAY** to the previous day, Sunday in this case. Setting the prices in the schedules is done in the **PRICE MENU**.

The following instructions can be used for both Schedule 2 and 3.

NOTE:

In order to activate an **AUTO PRICE** Schedule, the **PRICE SCHED-AUTO N** in the **PRICE MENU** must be selected after setting the time periods (See **PRICE SCHED-N ACTIVE** section).

This document is available free of charge to our customers
www.automatic

ENABLE SCHED N

The purpose of **ENABLE SCHED N** is to set the time period that price schedule N will be active.

To enable schedule N:

- 1) Press the **<SET>** key until **"ENABLE SCHED N - NO"** appears on the message center.
- 2) Use the **<UP>** or **<DOWN>** keys to display **"YES"**
- 3) Press the **<SET>** key.

START TIME

"START TIME - HH.MM XM" will appear on the message center. This shows the time of day that the schedule N prices will become active. To continue, press the **<SET>** key.

Set Start Time

"SET START TIME - NO" appears on the message center.

To set the start time:

- 1) Use the **<UP>** or **<DOWN>** keys to display **"YES"** on the message center.
- 2) Press the **<SET>** key.

Set Hours

"SET HOURS - HH XM" will appear on the message center.

To change the hour:

- 1) Use the **<UP>** or **<DOWN>** keys to display the correct hour
- 2) Press the **<SET>** key.

Set Mins

"SET MINS - MM" will appear on the message center.

To change the minutes:

- 1) Use the <UP> or <DOWN> keys to display the correct minutes
- 2) Press the <SET> key.

STOP TIME

"STOP TIME - HH.MM XM" will appear on the message center. This shows the time of day that the schedule N prices will become inactive. To continue, Press the <SET> key.

Set Stop Time

"SET STOP TIME - NO" appears on the message center.

To set the stop time:

- 1) Use the <UP> or <DOWN> keys to display "YES" on the message center.
- 2) Press the <SET> key.

Set Hours

"SET HOURS - HH XM" will appear on the message center.

To change the hour:

- 1) Use the <UP> or <DOWN> keys to display the correct hour
- 2) Press the <SET> key.

Set Mins

"SET MINS - MM" will appear on the message center.

To change the minutes:

- 1) Use the <UP> or <DOWN> keys to display the correct minutes.
- 2) Press the <SET> key.

START DAY

"START DAY-WWWDAY" will appear on the message center. This shows the day of the week that the schedule N prices will become active. To continue, press the <SET> key.

Set Start Day

"SET START DAY-NO" appears on the message center.

To set the start day:

- 1) Use the <UP> or <DOWN> keys to display "YES" on the message center.
- 2) Press the <SET> key.

Set Day

"SET DAY - WWWDAY" will appear on the message center.

To change the day:

- 1) Use the <UP> or <DOWN> keys to display the day.
- 2) Press the <SET> key.

END DAY

"END DAY-WWWDAY" will appear on the message center. This shows the day of the week that the schedule N prices will become inactive. To continue, press the <SET> key.

Set End Day

"SET END DAY-NO" appears on the message center.

To set the end day:

- 1) Use the <UP> or <DOWN> keys to display "YES" on the message center.
- 2) Press the <SET> key.

Set Day

"SET DAY - WWWDAY" will appear on the message center.

To change the day:

- 1) Use the <UP> or <DOWN> keys to display the day.
- 2) Press the <SET> key.

DISCOUNT MENU

The **DISCOUNT** menu contains the menu items that set the time periods during which the discounts will become active.

A time period is described by start and end times between and including the start and end days.

For example: If a discount is desired from 9:00AM to 5:00PM on Monday through Friday, set the **START TIME** to 9:00AM, the **STOP TIME** to 5:00PM, the **START DAY** to **MONDAY** and the **END DAY** to **FRIDAY**.

To describe a complete 24 hour time period, set the **START TIME** to some time, 9:00AM for example. Then set the **END TIME** to 1 minute less than that time, 8:59AM in this case.

To describe a complete week time period, set the **START DAY** to some day, Monday for example. Then set the **END DAY** to the previous day, Sunday in this case.

The following instructions apply to all three discounts.

SET DISCOUNT N

The purpose of **SET DISCOUNT N** is to set the time period that **DISCOUNT N** will be active.

To enable DISCOUNT N:

- 1) Press the <SET> key until "SET DISCOUNT N- NO" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to display "YES".
- 3) Press the <SET> key.

Discount

This menu item sets the amount that will be deducted from all prices in the active schedule when the discount is active.

If the discount is greater than or equal to the price of an item, the price will become \$.00.

To set the DISCOUNT:

- 1) Press the <SET> key until "DISCOUNT - \$

.XX" is displayed on the message center. (XX = .05 to 99.95.)

- 2) Use the <UP> or <DOWN> key to select the desired discount.
- 3) Press the <SET> key.

START TIME

"START TIME - HH.MM XM" will appear on the message center. This shows the time of day that Discount N will become active. To continue, press the <SET> key.

Set Start Time

"SET START TIME - NO" appears on the message center.

To set the start time:

- 1) Use the <UP> or <DOWN> keys to display "YES" on the message center
- 2) Press the <SET> key.

Set Hours

"SET HOURS - HH XM" will appear on the message center.

To change the hours:

- 1) Use the <UP> or <DOWN> keys to display the correct hour.
- 2) Press the <SET> key.

Set Mins

"SET MINS - MM" will appear on the message center.

To change the minutes:

- 1) Use the <UP> or <DOWN> keys to display the correct minutes.
- 2) Press the <SET> key.

STOP TIME

"STOP TIME - HH.MM XM" will appear on the message center. This shows the time of day that Discount N will become inactive. To continue, press the <SET> key. "SET STOP TIME - NO" appears on the message center.

To set the stop time:

- 1) Use the <UP> or <DOWN> keys to display "YES" on the message center.
- 2) Press the <SET> key.

Set Hours

"SET HOURS - HH XM" will appear on the message center.

To change the hours:

- 1) Use the <UP> or <DOWN> keys to display the correct hour.
- 2) Press the <SET> key.

Set Mins

"SET MINS - MM" will appear on the message center.

To change the minutes:

- 1) Use the <UP> or <DOWN> keys to display the correct minutes
- 2) Press the <SET> key.

START DAY

"START DAY-WWWDAY" will appear on the message center. This shows the day of the week that Discount N will become active. To continue, press the <SET> key.

Set Start Day

"SET START DAY-NO" appears on the message center.

To set the start day:

- 1) Use the <UP> or <DOWN> keys to display "YES" on the message center.
- 2) Press the <SET> key.

Set Day

"SET DAY - WWWDAY" will appear on the message center.

To change the day:

- 1) Use the <UP> or <DOWN> keys to display the day
- 2) Press the <SET> key.

End Day

"END DAY-WWWDAY" will appear on the message center. This shows the day of the week that Discount N will become inactive. To continue, press the <SET> key.

Set End Day

"SET END DAY-NO" appears on the message center.

To set the end day:

- 1) Use the <UP> or <DOWN> keys to display "YES" on the message center.
- 2) Press the <SET> key.

Set Day

"SET DAY - WWWDAY" will appear on the message center.

To change the day:

- 1) Use the <UP> or <DOWN> keys to display the day.
- 2) Press the <SET> key.

DIAGNOSTICS MENU

The **DIAGNOSTICS** menu contains the menu items that perform system diagnostics.

Health Test

The purpose of the **HEALTH TEST** is to test the health control system.

*To perform a **HEALTH TEST**:*

- 1) Open the service door and the large main door.
- 2) Locate the temperature probe on the inside bottom portion of the large main door near the fluorescent light.
- 3) Place a hand on the probe to raise the temperature above 45° F.
- 4) Check the temperature by depressing on the key pad the black <BLANK> key and then the <F> key.
- 5) The message center will temporarily display the "TEMPERATURE = XX F", where XX is the temperature being read by the probe.
- 6) When the temperature rises above 45° F, close the main door.
- 7) Use the <UP> or <DOWN> arrow keys to display "YES".
- 8) Press the <SET> key.
- 9) Close the Service door.
- 10) Press the black <BLANK> key and then the <H> key to display the health control status on the message center. The display should temporarily read "HEALTHCONTROL ON".
- 11) Wait approximately 20 seconds for the machine to go out of service.

Card Credit

The purpose of the **CARD CREDIT** menu item is to test the Debit Card System (if installed).

The **CARD CREDIT** menu item shows the amount of Debit Card credit currently established when a Debit Card is inserted into the Debit Card reader. The machine will accept as much credit as the debit card system is programmed to transfer.

Depress the escrow return button on the Debit Card System to return the credit to the card. The **CARD CREDIT** display should then return to "CARD CREDIT - \$.00".

Set Zero Pos

The purpose of the **SET ZERO POSITION** menu item is to locate the zero position on the turret.

To locate zero pos:

- 1) Use the <UP> or <DOWN> arrow keys to display "YES".
- 2) Press the <SET> key.
- 3) The message center will then display "TURN UNTIL ZERO POS" unless the turret is already located on the zero position switch.
- 4) If the turret is not on the zero position switch, turn the turret by depressing the <ROTATE LEFT TURRET> or <ROTATE RIGHT TURRET> key until the "TURN UNTIL ZERO POS" message disappears from the message center.

DEFAULT MENU

The **DEFAULT** menu contains menu items that perform machine initializations.

Machine Init

MACHINE INIT allows the machine to be initialized to a default setting.

There are two types of machine initializations; **FULL** and **OPTIONS**.

The **OPTIONS** initialization resets only the 548 options to default states. This type of initialization will turn off all the options that can be set in the **OPTIONS MENU**. (See **OPTIONS MENU** section).

*To perform an **OPTIONS** initialization:*

- 1) Use the <UP> or <DOWN> key to display "MACHINE INIT - OPTIONS" on the message center.
- 2) Press the <SET> key.

The **FULL** initialization resets the 548 to default states. This type of initialization will initialize the entire machine: **PRICES**, **MIS** totals (except for the non-resettables), **OPTIONS**, **TURRET DELAYS**, **AUTO PRICES**, and **DISCOUNTS**.

*To perform a **FULL** initialization:*

- 1) Use the <UP> or <DOWN> key to display "MACHINE INIT - FULL" on the message center.
- 2) Press the <SET> key.

Print Baud Rate

The purpose of **PRINT BAUD RATE** is to set the baud rate of the printer. There are three baud rates that may be chosen. They are 9600, 2400, or 1200.

The Default baud rate is 9600.

To set the baud rate:

- 1) Press the <SET> key until "PRINT BAUD RATE-BBBB" appears on the message center.
- 2) Use the <UP> or <DOWN> keys to choose between 9600, 2400, or 1200 depending on the particular printer in use. (Check printer manual for printer baud rate).
- 3) Press the <SET> key.

BLIND OPERATOR FEATURE

This feature will help assist blind operators in servicing the machine in the pricing menu.

- 1) Set the Universal Control Board DIP switch 1 to the ON position to enable the Blind Operator Feature.
- 2) Close the service door momentarily to restart the **SERVICE MENU**.
- 3) The **SET PRICE MENU** will now initialize to .00 cent each time. It will stop at .00 and \$99.95 while decrementing and incrementing.
- 4) The **PRICE MENU** will now be accessible directly by pressing the middle top gray service key before trying to access the **SERVICE MENUS**.

Section 4

TROUBLESHOOTING

INTRODUCTION

This section contains a preliminary check list, a Power Supply Indicator Light Identification Table and three troubleshooting charts. The first chart lists possible problems and suggested solutions. The second lists Error Messages which will be shown on the Message Display Center when in the Service Mode. And the third lists possible malfunctions with the Refrigeration unit.

When a problem occurs, always look for the obvious solution first. Check the following before attempting to make any adjustment or replace any parts:



Check List

- ✓ Check that the merchandiser is connected to a live power source with a good ground.
- ✓ Check that the main power switch is ON.
- ✓ Check the condition of both circuit breakers on the main power switch assembly, the four circuit breakers on the power supply cover, and the one on the power supply unit behind the center panel of cabinet.
- ✓ Check to insure both interlock switches are actuated when cabinet door is closed and latched.
- ✓ Check that all plugs are seated in their receptacles.
- ✓ Check that connector pins are not bent, broken or pushed through the back of the connector housing when mated.
- ✓ Check that wires are not broken at connector pins.
- ✓ Check all indicator LED's on the UCB and Power Supply Asm.

Indicator Lights

Voltage source problems are indicated by LED indicator lights located on the power supply. A representation of the Power Supply Cover showing the approximate location of these lights is described on page 4 - 8. Below it is a table describing what the indicator lights are monitoring. This will help you quickly isolate most voltage source problems.

Troubleshooting Charts

Each time the Universal Control Board is powered up it performs a series of tests to determine if specific components are functioning properly. As the machine goes through its various cycles during vending there are a number of routines which monitor the machine's performance and record any malfunctions. If a problem is encountered an Error Message indicating the type of problem is stored in the Universal Control Board's memory. The memory is battery backed and will not be affected by routine power outages.

If an error code occurs the machine will attempt to continue to operate normally. It should be noted however, that certain errors will make it necessary to disable some functions.

For example: If the lock bar solenoid fails to lock the doors it would be necessary not to allow the turret to rotate. This would prevent someone from taking out items through the unlocked doors which haven't been paid for.

Error Messages

For a listing of the Error Messages see the *Troubleshooting Chart - Error Messages*, pages 4 - 10 & 4-11. To view and clear Error Messages see Service Mode Operation, page 3 - 1.

The 548 has self diagnosing software to identify problem conditions. The operator is alerted using error messages rather than error codes.

If the error occurs while the coin mech door is open (service mode), an immediate temporary descriptive message is displayed. If the error occurs while the coin mech door is closed (vend mode), the error message is added to an error queue. If there are any error messages in the error queue at the start of service mode, they will be displayed in the order in which they occurred. The <SET> key is used to advance to the next message.

After all the messages have been viewed, the operator will be given the option of clearing the message queue. If the queue is not cleared, the error messages will continue to appear each time the coin mech door is opened to start the service mode.

OUT OF SERVICE

When a serious error condition occurs or exists while in vend mode, the machine will be put out of service. If there was credit established at that time, it will be returned. All of the money handling devices will be disabled. The Message Center will display "SORRY-OUT OF SERVICE" and the fluorescent lights will be turned off.

Turret Motor Errors

Upon full initialization, the turret motor zero position is reset and needs to be located. The zero position is indicated via the activation of a magnetic switch mounted on the main door by a magnet mounted on the turret. The main door must be closed to find zero position. The zero position will also need to be found if any motor error occurs either in vend mode or service mode.

NOTE:

Each time the machine is turned ON, the turret will rotate until zero position is located. An error message will be generated if the zero position cannot be located.

If the error occurred in vend mode, the machine will be put out of service, the motor will be disabled and the error message will be inserted into the error queue.

If the error happens while in service mode a temporary error message will be displayed. Another temporary error message will appear each time the turret motor is turned until zero position is located again. This can be done in the Diagnostic Menu.

If a motor error occurred while the service switch is on, the temporary message will be displayed and the motor will be stopped. To restart the motor, the service switch must be turned off and then on again.

COIN MECH PROBLEMS

The coin mech is required for machine operation in vend mode except when free vend is active. Upon power up and each time the coin mech door is closed, the reset line on the coin mech is toggled which results in the coin mech sending a power-up message to the UCB. If that message is not received in the specified time period, the "COIN MECH NO REPLY" message will be displayed. The machine will be put out of service if this occurs in vend mode. The probable cause of this error is that the coin mech is not plugged in. During service mode, the coin mech is enabled at all times and coins should be accepted. If coins are not being accepted, make sure the coin mech is receiving power from the power supply by pressing the coin payout buttons and listening for the solenoids energizing. If no solenoids are energized, then examine the power connections in the coin mech harness. If the solenoids do energize but the coin mech is not accepting coins in service mode, examine the accept-enable connections in the coin mech harness.

INITIAL POWER UP

Upon power up, the column display should show:

11111
22222
33333
44444
55555
66666
77777
99999
AAAAA
BBBBB
CCCCC

The displays will remain unchanged until the Universal Control Board sends them messages. If any of the column display tubes fail to "light up" the column display harness should be tested to ensure that power is being supplied.

The Message Center will display a "KEYPAD-DISPLAYVX.X" message upon power up. The display will remain unchanged until the Universal Control Board sends it a message. If the Message Center fails to "light up" the Message Center harness should be tested to ensure that power is being supplied.

When the UCB software starts up, it sends a 548 software revision identification message to the Message Center for a few seconds. The display should then change to service menu, assuming that the coin mech door is still open. The column display will then receive the compartment prices.

The Test LED on the Universal Control Board will begin to flash indicating that the processor is running. In general, the LED should always be flashing; though there are times when it will stop flashing momentarily during certain normal processing.

If the power up message of either display remains after the UCB Test LED begins flashing, then there is no communication between the UCB and that display and the harness should be examined.

Power-Up Initialization

The UCB features 8 Kbytes of battery backed up RAM enabling the software to "remember" the state of the 548 if power is interrupted for any amount of time.

The advertised approximate life of this battery is 10 years. When power to the machine is restored, the prices, options, MIS information etc. are the same as when the power was lost.

Each time the UCB is powered up, two tests are executed to determine if initialization is necessary. One test examines two memory locations for a specific test pattern. The other test performs a memory checksum calculation on most of the code section of UCB EPROM. If either test fails, a full software initialization will take place. This should occur each time a new EPROM is installed.

After initialization, all options are disabled, MIS information is cleared, the prices are set back to default etc. The default prices for schedule one are \$99.95 for all shelves. The prices for schedules two and three start at 5 cents and increment by 5 cents starting at shelf A, schedule two and ending at shelf K schedule three.

The operator may also manually initialize the machine via the Default service menu. There are two selectable types of initialization available; options and full. The options initialization will initialize all the options found in the Options menu to their default state. The full initialization will work as described above except that the nonresettable MIS totals will not be cleared.

REFRIGERATION SYSTEM

If the refrigeration system compressor is inoperative, perform the following checks before replacing the unit. Be sure to hold the Refrigeration Interlock Switch closed when making the operational checks.

NOTE:

When the refrigeration door interlock switch is depressed, a one minute power up delay to the compressor circuit will occur.

1. Measure the line voltage. If line voltage is below 105 volts, the compressor may fail to start, or run hot.
2. If line voltage is correct, check automatic control thermostat operation by connecting a jumper wire across the terminal with power disconnected.
3. The Start Capacitor, Run Capacitor, and Start Relay are best tested by substituting them with known good components. This way there can be no doubt of test results.
4. Check Thermal Overload for continuity.
5. With motor leads disconnected from circuits, check compressor motor windings with Volt/Ohm meter set on R x 1 scale.

(Readings +/- 10%)

Common to Start 5 Ohms
 Common to Run 1 Ohm
 Start to Run 6 Ohms

6. Check for grounded winding with Volt/Ohm meter from Start Capacitor to metal casing and Run Capacitor to metal casing. There should be no continuity, if there is, replace compressor.

COMPRESSOR CIRCUIT DESCRIPTION

The Compressor Motor is a Two Value Capacitor Motor. This is very similar to a Permanent Split Capacitor Motor except for the addition of a Running Capacitor. During start-up, both the Running and Starting Capacitors are in the circuit. This makes the total Capacitance during start between

98 FD and 113 FD. Once the Motor is running the capacitance is reduced to 25 FD.

The overall effects of a Running Capacitor are:

- Increases break down torque 30%
- Reduces full-load current
- Reduces full-load noise
- Increases locked rotor torque 20%
- Increases overall efficiency

The Start Relay contact is normally closed. The Start Relay has a voltage sensitive coil that remains de-energized until the voltage across its coil, caused by the voltage across the Start Winding, exceeds 162-175 VAC. At this time the compressor has broken away from the load and is near its nominal running speed. As the Compressor shaft speed increases, the voltage on the Start Winding also increases. When the Start Winding voltage reaches the proper level the Start Relay coil will energize. This opens the contacts to the Start Capacitor, disconnecting it from the circuit. With the Start Capacitor disconnected, the current through the Start Winding will drop 70%. The Bleeder Resistor provides a safe discharge path for any stored charge in the Start Capacitor. Failure to return the Start Relay and the Control Box to their correct mounting position will cause the motor starting voltages to be altered. This could result in start-up problems at low line voltages.

Always secure the Control Box before returning the unit to service.

The table below lists the DC resistance of components used in this merchandiser. If the troubleshooting chart indicates a motor or a solenoid malfunction, test the coil with an ohmmeter as instructed below.

TABLE 4 - 1 Component Resistance

| Description | Resistance (OHM +/- 10%) | Part No. |
|---------------------|--|----------|
| Door Latch Solenoid | 9 Ohms Reverse meter leads for approximately .2 Ohms difference | 548-1857 |
| Lock Bar Solenoid | 4.8 (Diode in place) Reverse meter leads for approximately .2 Ohms difference | 548-1854 |
| Transport Motor | 10 Ohms | 548-1815 |

CAUTION!

This is a HIGH Energy Circuit. DO NOT use less than 16 gauge wire or switches rated less than 15 amps. DO NOT connect the jumper wire or switch while power is ON.

When power is applied to the black wire, the Evaporator Blower should run immediately. Connecting the black wire to the YL/BK wire closes the refrigeration circuit. When the YL/BK wire is made hot, the condenser fan and compressor will start to run. Until the compressor rotor shaft reaches a minimum running speed, the start relay contact (Terminal 1 & 2) will remain closed. This allows the start capacitor to draw high current through the

start winding. This creates a high torque at the rotor shaft in order to accelerate the Compressor under load. As the rotor comes up to speed, the voltage on the start relay coil (Terminals 2 & 5) will rise. When the minimum running speed is attained, the Start Relay coil will energize and open the circuit to the Start Capacitor. When repairing the refrigeration unit only use EXACT replacement parts for the Start Relay, Run and Start Capacitors. Failure to do so will void the warranty. Please note the placement of the Start Relay and the Control Box. Both must be returned to the proper orientation. Altering the mounting position for either of these parts will change the starting voltage. Relay, Run and Start Capacitors.

Backup Refrigeration Unit

Normal Operation:

1. The UCB provides a pulse output at J11 pin 2 when controller is OK.
2. The UCB sends out a PULSE signal along with VRTN and +24VDC to be monitored by the DM TIMER circuit board.

If all outputs are healthy, the backup relay is held energized. This keeps the refrigeration system operated by the UCB which controls the refrigeration relay with outputs VRTN and VREFRIG.

Backup Operation:

If one of the following symptoms occur, the DM TIMER will drop out causing transfer of the refrigeration circuit through the Cold Control Thermostat.

1. If missing PULSE from the UCB for approximately 10 minutes.
2. If missing +24VDC or VRTN, the DM TIMER would immediately loose its +24 and RNSNK outputs..
3. If temperature in the cabinet is above 80°F, the UCB will stop sending pulses until the teperature drops below 80° F.

When the DM TIMER has dropped out, the backup relay coil will de-energize, and transfer the refrigeration circuit through the Cold Control Thermostat.




Figure 4-1
Backup Refrigeration Schematic

Refrigeration System Wiring Diagram (Domestic)




Figure 4-2. Refrigeration Wiring Diagram (Domestic)

NOTE:

The entire Refrigeration Unit may be removed from the vendor and run on the bench to troubleshoot. Install a jumper wire capable of handling 10A (16 gauge) in the Refrigeration Relay harness connector and plug the power cord into 120V grounded receptacle. Do not allow unit to run for extended periods of time without the Cold Control. It could cause the Evaporator to freeze.

CAUTION !

Protective eye wear must be worn when testing refrigeration systems. This system is charged with 18oz. of 404a refrigerant. Repair should only be performed by technicians trained and experienced in refrigeration troubleshooting and safety procedures. Never introduce other refrigerants into this system. Operating temperature/pressure will be affected and the unit will not function properly and could be destroyed.

Refrigeration System Wiring Diagram (European)




Figure 4-2. Refrigeration Wiring Diagram (European)

NOTE:

The entire Refrigeration Unit may be removed from the vendor and run on the bench to troubleshoot. Install a jumper wire capable of handling 10A (16 gauge) in the Refrigeration Relay harness connector and plug the power cord into 220/240V grounded receptacle. Do not allow unit to run for extended periods of time without the Cold Control. It could cause the Evaporator to freeze.

CAUTION !

Protective eye wear must be worn when testing refrigeration systems. This system is charged with 16oz. of R-404a refrigerant. Repair should only be performed by technicians trained and experienced in refrigeration troubleshooting and safety procedures. Never introduce other refrigerants into this system. Operating temperature/pressure will be affected and the unit will not function properly and could be destroyed.

Power Supply Indicator Lights




Figure 4-4. Power Board Assembly Indicator Lights

| Name | Color | Description |
|----------------------|------------|--|
| +120 V PDC Coin Mech | Neon | 120 V Pulse DC for Coin Mech |
| 27 VAC Euro Coin | Yellow LED | 27 VAC for European Executive Coin Mechs and Card Systems. |
| In Service Coil | Red LED | ON Indicates that the Fluorescent Lamp Relay Coil is energized. |
| -24V Fil. Out | Red LED | On indicates that the Column Display Filament Voltage is present. |
| +24V VFD Power | Red LED | On indicates that the -24V Cathode Supply is present. This is used to power the Column Display Message Center. |
| +5V Logic Power | Red LED | ON Indicates the presence of the +5 VDC Logic Supply. |
| +24V Solenoid Power | Red LED | ON Indicates the presence of the +24V Solenoid Supply. |
| Refrig Relay | Red LED | ON indicates power output to energize the refrigeration relay. |

Coin Mechanisms

120V Models - 12 or 15 Pin

MARS TRC - 6000

COINCO 9300L


24V Models - 15 Pin Only

MARS TRC - 6010 - XV

COINCO 9302LF

CAUTION !

Do not use a 24 volt Coin Mech with a 12 pin plug. This will result in permanent damage to the Coin Mech and / or the vendor.



1. +5 VDC
2. 5V RTN
3. Send
4. Int.
5. Data
6. Accept Enable
7. Dis \$.25
8. Dis \$.10
9. Dis \$.05
10. -120V PDC
11. Reset
12. +120V PDC
13. -24V PDC
14. Dis \$1
15. +24V PDC

**15 Pin
Coin Mech Socket**

Figure 4-5. 15 Pin Coin Mech Socket

This document is available free of charge to our customers
www.automaticproducts.com

Troubleshooting Chart Error Messages

| ERROR MESSAGE | PROBABLE CAUSE | SOLUTION |
|------------------------------|--|--|
| "MOTOR MALFUNCTION" | Turret Motor jammed error, return to zero position | Clear jam, clear motor |
| | Turret overloaded | Same as above |
| | Shorted motor leads | Remove short, clear error, turn to zero position |
| | Bad driver circuit on Power Supply | Replace power supply |
| | Bad detection circuit on Power Supply | Replace power supply |
| "HEALTH TIME EXPIRED" | Refrigeration unit not plugged in | Check and replug |
| | Refrigeration screen on condensor clogged | Check and clean |
| | Refrigeration relay disconnected or defective | Check and/or replace |
| | Machine too close to the wall | Move away from wall at least 6" |
| | Main door not closed tightly | Check and readjust latches |
| | High ambient temperature | Vendor not designed to operate outside |
| | Temperature reads 96° F continuously | Temperature Sensor not plugged in, or defective |
| "MAIN DOOR OPEN" | Faulty refrigeration system | See pages 4 - 3, 4 - 4, 4 - 5, 4 - 15 and 4 - 16 |
| | Switch not activated | Check Main Door and switch adjustment |
| | Switch broken or defective | Replace switch |
| | Switch disconnected | Check wiring |

Troubleshooting Chart Error Messages Continued

| ERROR MESSAGE | PROBABLE CAUSE | SOLUTION |
|-------------------------------|--|--|
| "HALF CYCLE SWITCH" | Half Cycle Switch disconnected or defective | Check wiring at Half Cycle Switch Replace Switch |
| | Motor Interlock Switch disconnected or defective | Check wiring at Motor Interlock Switch Replace Switch |
| | Half Cycle signal to Controller disconnected or defective | Check I/O Cable between Power Supply P6 to Controller board P6 |
| | Logic circuit on Power Supply defective | Replace Power Supply Asm. |
| | Inline fuse to motor opened | Replace Fuse Check F4 (PICO fuse) on P/S (P/S 548-1860 Only) |
| "ZERO POSITION ERROR" | Unable to locate zero position | Check Zero Position Switch, wiring, and magnet |
| | Machine initialized, no zero position located | Same as above |
| | Possible Motor Error | Check Motor wiring connections |
| | UCB unable to monitor turret movement | Check Half Cycle Switch on motor |
| "LOCKBAR SOL ERROR" | Defective Driver on UCB | Replace UCB |
| | Defective Power Supply | Check power supply for 24 VSOL lamp |
| | Bad lockbar solenoid wiring | Check wiring for lockbar solenoid |
| | Defective Solenoid | Replace Lockbar Solenoid |
| "LOCKBAR SWITCH ERROR" | Bad lockbar switch | Check lockbar switch wiring Replace Switch |
| "DEFECTIVE SENSOR MSG" | Defective coin tube sensor | Check Coin Mech Replace Coin Mech |
| "COIN JAM MSG" | Coin lodged between acceptance gates. | Check and clear jam Clean Flight Deck Replace Coin Mech |
| "NO STROBE MSG" | Valid coin has been recognized but not detected passing through to the inventory tubes or to the cash box. | Check for blockage in Coin Mech Replace Coin Mech Check payout switches for operation. If not operating, Check P/S 120VPDCLED. If out replace F1 fuse on power supply board. |
| "COIN MECH NO REPLY" | Coin mech unplugged or defective coin mech | Check Coin Mech Connection Replace Coin Mech |
| "BAD TEMP PROBE" | 5VDC line to temp probe open | Check red wire connection at probe and P9 of the UCB. Check continuity between P9 pin 2 (red wire) to interconnect of temp. probe. If Okay, replace probe. |

Troubleshooting Chart (Problem / Solution)

| PROBLEM | PROBABLE CAUSE | SOLUTION |
|-------------------------------------|---------------------------------|--|
| Message Center does not light | No power to the Message Center | Check for +5 VDC |
| | | Check for VRTN Above voltages are required for the Message Center to light. There is only one cable to the Message Center. This comes from the Controller Board. If the Controller dies but power is still on the Message Center, the Message Center will default to the built in message "KEYPAD-DISPLAY VX.X" |
| Price Column display does not light | Missing Power | Check Power Supply -24V VFD POWER light indicator |
| | Harness/Connector Problem | Check from P/S (P7) to Display (P1) |
| | Defective Column Display | Replace |
| Does not accept coins | Missing Power | Check Power Supply 120 PDC Light Indicator |
| | Harness/Connector Problem | Check Coin Mech Socket, UCB (P8) and P/S (P3) |
| | Defective Coin Mech | Replace |
| Does not attempt acceptance | Missing Power | Check power light on Power Supply |
| | Coin Mech change level low | Add change to Coin Mech |
| | Improper coin loading technique | See Coin Loading routine page 2 - 2 |
| | Harness/Connector Problem | Check I/O UCB (P5) to B/A (P2 - P3) |
| | Bill Acceptor not enabled | Check Options Menu program on page 3 - 19 to see if B/A is enabled |
| | Defective Bill Acceptor | Replace |

Troubleshooting Chart (Problem / Solution)

| PROBLEM | PROBABLE CAUSE | SOLUTION | | | | | | | |
|---------------------------------|---|--|-------|-------|-------|-------|-------|-------|-------|
| Does not register credit | Credit messages not received from Coin Mech | No continuity between J8 pin 9 of UCB and pin 5 of Coin Mech plug | | | | | | | |
| | Coin Mech defective | Replace Coin Mech | | | | | | | |
| | Service Door switch not closed | Check for defective actuator | | | | | | | |
| Does not give change | Coin Mech mis-programmed | Reload Coin Mech. See page 3 - 10 Set Coin Tubes | | | | | | | |
| | | Check continuity between: <u>Controller J8</u> <u>Coin Mech</u> | | | | | | | |
| | Dispense lines to Coin Mech disconnected | <table><tr><td>pin 3</td><td>pin 9</td></tr><tr><td>pin 4</td><td>pin 8</td></tr><tr><td>pin 5</td><td>pin 7</td></tr><tr><td>pin 7</td><td>pin 14</td></tr></table> | pin 3 | pin 9 | pin 4 | pin 8 | pin 5 | pin 7 | pin 7 |
| pin 3 | pin 9 | | | | | | | | |
| pin 4 | pin 8 | | | | | | | | |
| pin 5 | pin 7 | | | | | | | | |
| pin 7 | pin 14 | | | | | | | | |
| Turret does not rotate | Defective controller board | Replace controller board | | | | | | | |
| | Dollar coins in MIS | Empty dollar coins | | | | | | | |
| | Harness/Connector problems | Check terminals on Motor Check P/S (P4) BK/OR & BL/OR wires to motor terminals Check UCB (P6) to P/S (P6) Check UCB (P2) to Message Center | | | | | | | |
| | No signal from Message Center | Replace defective Message Center | | | | | | | |
| | UCB ON/OFF output signal missing | Measure P/S (P6 pin 11) to (P5 pin 2 ground) for 12 VDC with Service Switch ON Replace UCB if missing voltage | | | | | | | |
| Turret only turns one direction | Turret overload or jammed | Replace P/S if voltage is present | | | | | | | |
| | DC Motor defective | Remove obstruction Check for 24VDC across motor, if present, replace. If not, check in-line fuse. Check F4 (PICO Fuse) on P/S. (P/S 548-1868 Only) | | | | | | | |
| | Key Stuck on Message Center | Disconnect harness. If turret stops replace Message Center | | | | | | | |
| | Service Switch defective or shorted to door | Check Switch Perform continuity test between switch and door chassis for wire short | | | | | | | |

Troubleshooting Chart (Problem / Solution)

| PROBLEM | PROBABLE CAUSE | SOLUTION |
|--|--|---|
| Turret only turns one direction | UCB Dir output signal missing | Measure across P/S (P6 pin 9) to (P5 pin 2 ground) for 12 VDC Replace UCB if missing voltage Replace P/S if voltage is present |
| | Harness/Connector problems | Check UCB P6 to P/S P6, BL/BK wire for continuity |
| | Message Center Rocker Sw. defective | Replace message Center |
| Turret stops between lobes on cam | Defective power supply | Replace power supply |
| Turret Rotates constantly | Key stuck on Message Center | Disconnect harness from Message Center, if turret stops replace Message Center |
| | Service Switch defective or shorted to door | Check Switch Perform continuity test between switch and door chassis for wire short |
| | Half cycle switch defective, or wiring defective or unplugged. | Check switch for adjustment and wiring for continuity |
| Vend Door does not open | Turret out of position and/or in FIFO Mode | Check Turret position Set Zero Position routine in the Diagnostic Menu. |
| | | Reprogram Shelf Mode |
| | Compartments in sold condition | Rotate the Turret one full revolution with inside Service Switch Check the Sold Out Check program in Options Menu. See page 3 - 19 |
| | Invalid section lockout | Check the Prohibit Vend Program in Options Menu. See page 3 - 22 Check Solenoid resistance Table 4 - 1. See page 4 - 4 |

Troubleshooting Chart Refrigeration

| PROBLEM | PROBABLE CAUSE | SOLUTION |
|----------------------------------|-------------------------------------|---|
| Vend Door does not open | Defective solenoid | Replace Solenoid |
| | Defective door switch | Replace Switch |
| | Missing VSOL from Power Supply | Check P/S +24 VSOL POWER indicator light. Replace Power Supply |
| | Defective solenoid driver on UCB | Replace UCB |
| Health Control shutdown | Temperature Probe defective | Press the <BLANK> then <F> key to display temperature. If actual temperature is different from display, replace Temperature Probe |
| | Evaporator Freeze up | Make sure unit is level |
| Refrigeration inoperative | Refrigeration problem | See following Troubleshooting problems |
| | Refrigeration unplugged or no power | Check and replug |
| | Refrigeration relay unplugged | Connect Refrigeration relay |
| | Refrigeration overload | Clean screen and condenser coils |
| | Relay (control) defective | Perform the following: Power Unit OFF. Short together the (blk) and (blk/y) wire on the Refrig. Relay Power Unit ON |
| | | If (A & B) hold true, replace the Refrigeration Relay: A. (Power Supply Asm.) Refrig. Relay lamp is lit. B. Refrigeration Unit now powers up. |

Troubleshooting Chart Refrigeration


| PROBLEM | PROBABLE CAUSE | SOLUTION |
|--|--|--|
| Compressor does not start | No voltage on (bk) wire with Evaporator/Blower not running | Defective Refrigeration Unit line cord |
| | No voltage on (yl/bk) wire | Check and/or replace Refrig. Relay |
| | Low line voltage | Check voltage. It should be 105V minimum with Compressor running |
| | Start Relay contacts defective | Replace Start Relay |
| | Motor overload defective | Check and replace |
| | Start Capacitor defective | Check and replace |
| | Compressor Head load too high | Allow 3 minutes off time for pressure equalization before restarting and performing pressure checks |
| | Compressor Start winding defective | Perform Compressor Ohm test. See page 4 - 3 of (Refrigeration System), if fails test, replace Compressor, Start Relay, Start Cap and Run Cap |
| | NOTE: Motor will start with Run Capacitor removed or open. | |
| | Air intake screen clogged or obstructed | Clean as necessary |
| Compressor runs hot, trips overload | Condenser coils blocked | Clean as necessary |
| | Condenser fan not running | Remove obstruction or replace |
| | Start Relay not opening, defective | Check and replace |
| | Run Capacitor not in circuit | Check and install |
| | Run Capacitor defective | Check and replace |
| | Low line voltage | Check voltage. It should be 105V minimum with compressor running. |
| | Low refrigerant charge | Allow 3 minutes off time for pressure equalization before performing pressure checks. |

This document is available free of
charge to all our customers at
www.automaticproducts.com





This page intentionally left blank.

This document is available free of
charge to our customers
www.automaticproducts.com





4-19





For Equivalent Engineering Drawing, See 28029500 D
Figure 4-7A. Controller Board Schematic, Sheet 1





For Equivalent Engineering Drawing, See 28029500 D
Figure 4-7B. Controller Board Schematic, Sheet 2





Figure 4-8A. 548 Power Supply Schematic, Sheet 1









Figure 4-8B. 548 Power Supply Schematic, Sheet 2



This document is available for free of charge to our customers at www.automatedproducts.com



For Equivalent Engineering Drawing, See 28096900
Figure 4-9. Message Center Display Board

This page intentionally left blank.

This document is available free of
charge to our customers
www.automaticproducts.com

Section 5

MAINTENANCE

INTRODUCTION

This section contains adjustment, repair and replacement procedures. All lubrication has been done at the factory and no further lubrication is required.

ADJUSTMENTS

The Showcase Merchandiser is adjusted at the factory for optimum performance and requires no additional adjustments unless parts have been repaired or replaced. Before attempting to make any adjustments to a mechanism, consult the troubleshooting charts to verify the need.

DELIVERY DOOR SWITCH

With delivery door closed, the switch should be open. When the delivery door is opened, the switch actuator should be making contact with the raised part of door follower and the switch should be closed. To adjust, loosen the switch mounting screws and rotate.

1. Turn the main power switch OFF.
2. Loosen both mounting screws and the unlatch solenoid assembly.
3. Hold the delivery door open 1-3/4" (use wood block).




Figure 5-1. Delivery Door Switch




Figure 5-2. Lock Bar Switch
Delivery Door Interlock Switch

4. Place a .093" gauge under switch roller. Adjust the switch until the actuator "bottoms."
5. Remove the gauge and door block and check for switch roller operation. Make certain there is no binding.

LOCK BAR SWITCH

The switch should normally be making contact with the vertical edge of the "cam" and the switch should be "open." When the solenoid is energized, the switch actuator will fall off the beveled edge of the cam and the switch should be "closed."

Adjust as follows:

1. Turn the main power switch OFF.
2. Unlatch all delivery doors.
3. Connect the continuity light to the switch (common and normally closed).
4. Slowly close solenoid plunger. All latches must drop out before the light comes on.

- To adjust, loosen the two screws on the switch bracket assembly (or switch mounting screws if necessary).

TRANS-MOTOR INTERLOCK SWITCH

Adjust as follows:

- Remove the top cover over the Delivery Door Latch Assembly.
- Be certain all of the delivery doors are completely closed.
- Manually unlatch any delivery door.
- While observing the Interlock Switch Actuator, **SLOWLY** open the unlatched door.
- The Interlock Switch Actuator must not travel vertically more than 1/32" - 1/16" to actuate Interlock Switch. The interlock switch must be actuated before the door switch is actuated to prevent turret rotation while the vend door is open.
- Loosen the screw on the nylon switch actuator (P/N 448-813) and adjust accordingly. (Interlock Switch **MUST** be in the Normal Closed position when all delivery doors are closed)
- Recheck after adjusting.

Repair and Replacement

Most of the repair and replacement procedures for the Merchandiser are of an obvious nature. The following information is provided to aid service personnel in repairing or replacing parts that require additional information.

CAUTION !

This Refrigeration Unit Contains R404a under pressure. Refrigerant contact with skin should be avoided and protective eye-wear must be worn. Repairs should only be attempted by qualified mechanics trained and skilled in accepted Refrigeration techniques and procedures.

NEVER introduce other refrigerants into this system. Operating temperatures & pressures will be affected and the refrigeration unit will not operate correctly, possibly damaging the unit.

CHECKING THE REFRIGERATION SYSTEM

NOTE:

The entire Refrigeration Unit may be removed from the vendor and run on the bench to troubleshoot any given problem. Install a jumper wire capable of handling 10A (16 gauge) in the Cold Control Thermostat harness connector, and plug power cord into 120V grounded receptacle.

DO NOT allow unit to run for extended periods of time because the Evaporator may freeze without the cold control.

If the refrigeration system compressor is inoperative, perform the following checks before replacing the compressor. Be sure to hold the Refrigeration interlock switch closed when making the operational checks.

- Measure the line voltage. If the line voltage is below 105 volts, the compressor may fail to start.
- If line voltage is correct, check the automatic control thermostat operation by connecting a jumper wire across the terminal with the power disconnected.
- The Start Capacitor, Run Capacitor, and Start Relay are best tested by substituting them with known good components. This way there can be no doubt of test results.
- Check Thermal Overload for continuity.
- Check compressor motor windings with Volt/Ohm meter set on R + 1 scale. (Readings +/- 10%)

| | |
|-----------------|--------|
| Common to Start | 5 Ohms |
| Common to Run | 1 Ohm |
| Start to Run | 6 Ohms |
- Check for grounded winding with Volt/Ohm meter from Start to metal casing and Run to metal casing. There should be no continuity. If there is, replace the compressor.

CAUTION !

To prevent injury or damage to the vendor, two people are required to perform the following procedure.

7. Check the high pressure cut-out switch. It is located on the compressor discharge line. Push the button to reset.

TURRET REMOVAL

1. Empty Turret of all product to prevent spillage.
2. Rotate Turret until the "zero" position magnet is facing straight forward and shut off the Main Line Switch.
3. Empty and remove the four storage racks.
4. Remove the single screw at the base of the dividing wall, slide it forward and remove.

NOTE:

A long handled 1/4" Spintlite (12' or more) with a magnetized head, is recommended for step 5.

5. Remove two screws from upper pivot bearing. The bearing and pivot shaft will lay down on top of the turret.
6. Lift the turret assembly straight up high enough for turret base to clear the center bearing and drive helicopter and remove the turret.
7. Reverse this procedure to reinstall the turret.

CAUTION !

The white cover over the delivery door unlatch mechanisms being removed in step 2 of this procedure must be replaced correctly to ensure anti-cheat protection. The edges of the cover must be installed behind the lip on the delivery door runners.

DELIVERY DOOR REMOVAL

1. Remove the left hand fluorescent lamp and the white cover over the delivery door unlatch mechanisms.
2. Remove the four (4) screws from the bottom Runner of the door being replaced. (One screw on the right end of runner, 3 screws on left side of delivery door opening).
3. Remove the anti-spread bar.
4. Slide the bottom runner out to the left.
5. Lift the bottom of the door out first, then the top.

6. Unhook the delivery door return spring.
7. To replace, reverse the above procedure.

CLEANING

To project the best selling image to the customer, and to prolong the beauty and operation of the vendor, it is important to keep your Showcase Merchandiser clean.

Door Fan Filter

Check and wash out the door fan filter each month or as needed depending on location. If not cleaned for long periods, the efficiency and life expectancy of the fan motor and heating element will deteriorate.

Unit Exterior

Remove any debris lodged in the vend door runner tracks. Use a clean soft cloth moistened with a mild rated plastic cleaner to clean all vend doors and runner tracks. Metal and vinyl surfaces can be cleaned with warm water and a mild non-dulling detergent.

Unit Interior

Remove any debris that may have spilled or dripped into the compartments, interior lining and shelf areas. Use a clean lint-free cloth, moistened with a mild plastic rated cleaner.

Coin Mech

Check and clean regularly the coin paths leading through the flight deck and coin tubes. Use a lint-free cloth, moistened with a mild detergent.

Refrigeration System

The refrigeration intake screen should be checked routinely. It is easy to remove with the main door open.

The condenser coil and exhaust screen should be checked and cleaned at least once a year. These areas should be checked more often if the location is dusty or dirty.

The entire refrigeration unit needs to be pulled out to clean the condenser coil and exhaust screen. The process of removing the refrigeration unit is simple and easy and should only take about five minutes.

Follow the instructions on the next page.

Cleaning the Refrigeration Unit

1. Turn OFF the main power switch.
2. Remove the screws securing the right refrigeration cover, located at the lower front of the cabinet.
3. Unplug the 6 connectors on the power supply panel.
4. Remove the top center screw on the power supply panel and the screw to the right of the right most power supply hinge, then rotate the power supply forward.
5. Disconnect the refrigeration AC power plug to the refrigeration system, and three pin harness connector.
6. Disconnect the 6-pin connector to transport motor.
7. Disconnect the harness to the backup thermostat.
8. Slide the power supply to the right to remove it from the hinges. Set the power supply aside.
9. Remove the screws securing the front mounting bracket holding the refrigeration unit.
10. Unlatch the left & right side refrigeration unit levers.
11. Slide the entire refrigeration system forward.
12. Clean out any debris in the air return housing.
13. Blow out and clean the condenser coil assembly.
14. Blow out and clean the cabinet rear exhaust screen.

NOTE:

Commercial products are available to clean the condenser. Follow the manufacturer's instructions.

Section 6

PARTS CATALOG

Parts Catalog Contents

| Fig. No. | Description | Pg. No. |
|----------|---|---------|
| 1 | Main Door and Trim Panels | 6-4 |
| 2 | Main Door (Exterior) | 6-6 |
| 3 | Message Center | 6-8 |
| 4 | Main Door (Interior) | 6-10 |
| 5 | Lower Main Door Components | 6-12 |
| 6 | Coin Mech Compartment | 6-14 |
| 7 | Door Assembly - Coin Mech Compartment | 6-16 |
| 8 | Delivery Door Panel Assembly | 6-18 |
| 9 | Cabinet Final Assembly | 6-20 |
| 10 | Power Supply Assembly | 6-24 |
| 11 | Main Panel Switch | 6-26 |
| 12 | Turret Drive Motor Assembly | 6-28 |
| 13 | Turret Components - Bottom | 6-30 |
| 14 | Turret Drive and Roller | 6-31 |
| 15 | Lock Bar Solenoid | 6-32 |
| 16 | Refrigeration Unit | 6-33 |
| 17 | Universal Control Board | 6-35 |
| 18 | Power Supply Circuit Board Assembly | 6-38 |
| 19 | Harness List | 6-41 |
| 20 | European Part Numbers | 6-42 |
| 22 | Hardware List | 6-43 |
| | Index | 6-45 |

Optional Kits

| Part No. | Description | Function |
|-----------------|-------------------------|----------------------------------|
| 448-66019 | Universal Bill Acceptor | Allows Currency Acceptance |
| 548-06000 | Printer Harness Kit | Allows MIS retrieval via printer |
| 548-06003 | MARS VFM3 Adapter Kit | MARS B/A Useage |
| 548-06013 | Third Light Kit | Install Center Light |

This document is available free of
charge to our customers
www.automaticproducts.com

Parts Catalog

INTRODUCTION

This parts catalog contains a list of replacement parts for the vendor that are available. Each list contains an index of the part, the part number, a description of the part and the quantity required for the assembly. Separate parts of riveted or welded assemblies are not available from the factory as replacement parts.

Parts Callout

Each table in the Parts Callout contains four columns. Following is a description of each column in the order of appearance on the Parts Callout tables.

Fig. and Index No.

This column lists the figure number as the first entry on each page. An index number keys the part to the figure.

Part No.

This column lists the part number of the item that should be used for ordering. The same part, whenever used, retains the same number.

Description

This column gives the name of the assembly or part.

Quantity per Assembly


This column contains the exact quantity of the item required for its next higher assembly.

ORDERING REPLACEMENT PARTS

All parts must be ordered from an authorized part supplier. Parts orders are often delayed because of inadequate or incomplete ordering information. Be sure to include all required information which consists of:

1. The part number and description exactly as it appears in the Parts Catalog. State color if applicable.
2. Quantity being ordered.
3. Model and Serial Number of vendor for which the part is required. This is necessary because of Manufacturing changes.
4. Complete shipping address including ZIP code.
5. Specify shipping instructions. It is advisable to indicate an alternate shipping method if the packages may exceed the size and weight limits established by the shipping agency of your choice.

Main Door and Trim Panels



Main Door and Trim Panels

| Number | Description | Genesis | Award | Stellar | Imperial Crown |
|--------|----------------------------|-------------|-------------|--------------|----------------|
| 1 | Channel - Header | 983-3 | 983-3 | 983-4 | 983-3 |
| 2 | Insert - Header | 985-3-9 | 985-3-1 | 448-1477 | 985-3-2 |
| 3 | Trim - Sides Vertical | 983-101 | 983-101 | 983-100 | 983-101 |
| | Trim Retainer - Vertical | 983-325 | 983-325 | 983-325 | 983-325 |
| 4 | Overlay | 548-451 | 548-451 | 548-450 | 548-451 |
| 5 | Overlay | 548-421 | 548-421 | 548-420 | 548-421 |
| 6 | Panel w/UBA | 448-2531-9 | 448-2531-7 | 448-2531-79 | 448-2531-12 |
| | Panel w/o UBA | 448-30501-9 | 448-30501-7 | 448-30501-79 | 448-30501-12 |
| 7 | Overlay w/UBA | 448-2527 | 448-2527 | 448-2526 | 448-2527 |
| | Overlay w/o UBA | 448-2533 | 448-2533 | 448-2534 | 448-2533 |
| 8 | Overlay | 907-1088 | 907-1088 | 907-1088 | 907-1088 |
| 9 | Trim - Horizontal | 983-224 | 983-206 | 983-207 | 983-206 |
| | Trim Retainer - Horizontal | 983-329 | 983-329 | 983-329 | 983-329 |
| 10 | Panel | 448-12472 | 985-22-1 | 448-1478 | 985-22-2 |
| 11 | Kickplate (OPT) (Black) | 448-6028 | 448-6028 | 448-6028 | 448-6028 |
| 12 | Trim - Horizontal - Bottom | 448-743-239 | 448-743-246 | 448-743-246 | 448-743-246 |

Panel Styling Suffix Numbers

There are many combinations of panel and overlay finishes based on styling or individual company preferences. Part numbers for the styling overlays and panels are generally the same with the exception of last dash number which denotes the finish of the part.

NOTE:

Start with the basic part number obtained from Fig. 1 (Page 6-4) and substitute the last dash number for the "finish" desired.


HORIZONTAL PANELS

- 1 Rosewood
- 2 Presidential Walnut
- 3 Regency Walnut
- 4 Kashmir Walnut
- 9 Black
- 10 Golden Leather
- 79 Charcoal Brown

VERTICAL PANELS


- 5 Stainless Steel Mylar
- 29 Teak
- 32 Terra Cotta
- 69 Chamois
- 78 Sterling Royse
- 29 Teak
- 2 Presidential Walnut
- 7 Shadow Silver
- 11 Brushed Bronze
- 12 Port Au-Prince
- 15 Stainless Steel Mylar
- 78 Sterling Royse

Main Door (Exterior)



| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|-------------|--|-----------------------|
| | 548-01400 | Main Door Final Assembly | REF |
| | 548-01401 | Main Door Weld Assembly | 1 |
| 1 | 448-01309 | Pivot Plate Rivet Assembly Top (Also in Fig. 9) | 1 |
| | 921-00496 | Screw, Counter Sunk - Phillips (Not Shown) | 3 |
| 2 | 548-00411 | Extrusion - Glass - Top | 1 |
| 3 | 548-00416 | Lens - Display | 1 |
| 4 | 548-00463 | Extrusion - Runner Retainer - Top | 1 |
| 5 | 548-00468 | Panel, Air Duct | 1 |
| | 548-00470 | Seal, Air Duct (Not Shown) | |
| 6 | 408-00511 | Cap, Trim Top | 1 |
| 7 | 548-01402 | Coin Mech. Compartment Door Assembly (No Overlay) - See Fig. 6 | 1 |
| 8 | 500-01010 | Message Center/Coin Insert (See Fig. 3) | REF |
| 9 | 548-00449 | Bezel, Coin Insert | 1 |
| | 548-20500 | Bezel- Coin Insert - Univ. Cntrl. (European) | REF |
| | 924-00176 | Nut, Bezel Mounting (Not Shown) | 6 |
| 10 | 479-01420 | Pop-Out Handle Assembly (See Fig. 6) | 1 |
| | 903-00016 | Carriage Bolt, Handle Mounting | 2 |
| | 924-00037 | Nut, Handle Mounting | 2 |
| 11 | 490-00470 | Slide, Coin Return | 1 |
| 12 | 448-02525 | Bezel, U.B.A. | 1 |
| | 934-00383 | Screw, Bezel Mounting | 4 |
| | 448-02555 | Filler Plate (if U.B.A. is removed) | ALT. |
| | 934-00428 | Screw, Filler Plate Mounting | 2 |
| 13 | 448-02527 | See Door Style Page 6 - 4 | REF |
| 14 | 448-66019 | Universal Bill Acceptor | OPT. |
| 15 | 490-00408 | Bezel, Coin Return Cup | 1 |
| | 924-00176 | Nut, Bezel Mounting | 4 |
| 16 | 907-01088 | C/R Bezel Overlay (See Door Style Page 6 - 4) | REF |
| 17 | 448-21510 | Cup, Coin Return W/A (See Fig. 6) | REF |
| 18 | 448-00575 | Leg, Door Stabilizing | 1 |
| 19 | 408-00510 | Cap, Trim Bottom | 1 |
| 20 | 548-00423 | Sill, Bottom Right Side | 1 |
| 21 | 548-00464 | Extrusion, Runner Retainer - Bottom | 1 |
| 22 | 548-01806 | Price Display Assembly - Bottom | 1 |
| 23 | 548-00414 | Extrusion - Price Display | 1 |
| 24 | 548-00410 | Extrusion, Glass Bottom | 1 |
| 25 | 548-00422 | Sill, Bottom Left Side | 1 |
| 26 | 448-01407 | Pivot Plate, Rivet Assembly - Bottom (See Fig. 9) | 1 |
| | 921-00496 | Screw, Counter Sunk - Phillips (Not Shown) | 4 |
| 27 | 548-01800 | Heated Glass and Gasket Assembly (See Fig. 4) | 1 |
| 28 | 548-00472 | Trim, Door - Left Side | 1 |
| 29 | 548-01805 | Price Display Assembly - Center | 1 |
| 30 | 448-01428 | Delivery Door - 5" | 2 |
| | 448-01427 | Delivery Door - 4" | 9 |
| 31 | 548-01804 | Price Display Assembly - Top | 1 |
| 32 | 548-00437 | Locator PC Board | 1 |


Message Center



| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|---------------|--|-----------------------|
| | 500-01018 | Message Center Complete (Contains everything listed below) | REF |
| 1 | 500-01010 | Message Center Assembly (Contains ONLY parts indented below) | 1 |
| | 500-00100 | Overlay - Message Center | 1 |
| | 500-00101 | Housing - Keyboard | 1 |
| | 500-01011 | Keyboard Assembly & PCB | 1 |
| | 28096701 | Display Board | 1 |
| | 934-00307 | Screw | 5 |
| | 500-01017 | Harness (Not Shown) | 1 |
| | 500-00117 | Cover, Message Center | 1 |
| | 914-00007 | Push Fastener | 4 |
| 2 | 548-00434 | Keeper - Message Center Latch | 1 |
| | 934-00428 | Screw, Keeper Mounting (Not Shown) | 1 |
| 3 | 548-00800 | Grid - Button Keypad | 1 |
| 4 | 010-30873-226 | Pushbutton Set ("A" Thru "K") | 1 |
| 5 | 010-30838-111 | Pushbutton ("BLANK") | 1 |
| 6 | 548-00801 | Pushbutton, Rocker | 1 |
| 7 | 907-02191 | Label (Decal) Carousel Rotator | 1 |
| 8 | 548-00432 | Hinge, Message Center | 1 |
| 9 | 548-01819 | Harness - UCB P2 to Message Center | 1 |


This document is available free of
charge to our customers
www.automaticproducts.com

Main Door (Interior)




| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|-------------|--|-----------------------|
| | 548-01400 | Main Door Final Assembly | REF |
| | 548-01401 | Main Door Weld Assembly | 1 |
| 1 | 928-03500 | Gasket, Main Door Sealing | 1 |
| | 934-00448 | Screw | 44 |
| 2 | 548-01840 | Socket Assembly - Fluorescent Lamp - Top and Bottom | 2 |
| | 448-00549 | Socket - Fluorescent Lamp | 2 |
| 3 | 548-00438 | Liner, Door - Top | 1 |
| 4 | 448-14020 | Rail & Cover | 12 |
| | 448-00491 | Molding - Door Runner | 1 |
| | 448-00693 | Runner, Delivery Door - Top and Bottom Only | 2 |
| 5 | 448-02507 | Bracket, Centerpost - Upper (If so Equipped) | 1 |
| 6 | 548-00452 | Housing, Zero Position Switch | 1 |
| | 548-00453 | Pad, Zero Position Switch Retaining | 1 |
| | 548-01816 | Switch Assembly, Zero Position | 1 |
| 7 | 548-01419 | Cover - W/A Insulation | 1 |
| | 548-00517 | Insulation - Price Display (Under Cover) | 1 |
| | 548-00478 | Retainer - Glass, Center (Under Insulation) | 1 |
| 8 | 548-00413 | Retainer, Glass - Top | 1 |
| | 934-00448 | Screw - Retaining Mounting | 3 |
| 9 | 917-00114 | Lamp - Fluorescent | 2 |
| | 917-00200 | Safety Shield | 2 |
| 10 | 548-01800 | Glass and Gasket, Heated | 1 |
| 11 | 707-03904 | Service Switch | 1 |
| 12 | 907-02218 | Label - "Service Switch" | 1 |
| 13 | 548-00824 | Cover, Lamp / Harness Panel | 1 |
| | 548-01413 | Retainer - Glass, Right (Under Cover) | 1 |
| 14 | 548-00412 | Retainer, Glass - Bottom | 1 |
| 15 | 448-02804 | Bracket, Socket Mounting - Bottom | 1 |
| 16 | 548-01849 | Wire, Heater (Heater Strip Not Shown) | 1 |
| 17 | 548-00439 | Liner, Door - Bottom | 1 |
| 18 | 448-02506 | Bracket, Centerpost - Bottom (If so Equipped) | 1 |
| 19 | 448-02514 | Cover, Door Channel | 1 |
| 20 | 548-01818 | Probe, Temperature Sensing | 1 |
| | 548-00441 | Cover, Temperature Sensor | 1 |
| | 934-00307 | Screw, Cover Mounting | 1 |
| | 975-00602 | Clip - Type 5, Nylon | 1 |
| | 548-00506 | Insulator Plate - Temperature Sensor | 1 |
| 21 | 448-00555 | Cover, Harness | 1 |
| 22 | 448-12471 | Cover and Guard Weld Assembly | 1 |
| 23 | 448-00597 | Holder, Price Cards | 1 |
| | 934-00077 | Screw | 1 |
| 24 | 548-04005 | Bracket (Left) | 1 |
| 25 | 548-01410 | Delivery Door Mech Assembly - 4" | 9 |
| | 548-01411 | Delivery Door Mech Assembly - 5" | 2 |
| 26 | 448-14020 | Rail and Cover | 10 |
| | 448-14015 | Extension Runner (Not Shown) | 12 |
| | 448-00492 | Stop, Delivery Door (Not Shown) | A/R |
| | 448-00723 | Spacer, Large Compartment (Not Shown) | A/R |
| 27 | 448-00586 | Guard, Gasket - Main Door | 1 |
| * | 448-01917 | Selection Card Assortment - "A" thru "K" (Not Shown) | 1 |

Lower Main Door Components




| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|-------------|--|-----------------------|
| 1 | 448-02514 | Cover, Door Channel | 1 |
| | 934-00492 | Screw | 14 |
| 2 | 448-12403 | Cash Box Mounting Bracket W/A | 1 |
| | 934-00357 | Screw | 4 |
| 3 | 548-01847 | Switch, Heater / Fan Unit | 1 |
| 4 | 934-00357 | Label - Heater Blower | 1 |
| 5 | 548-00827 | Cover - Blower Enclosure | 1 |
| | 934-00151 | Screw | 6 |
| 6 | 448-00856 | Filter | 1 |
| 7 | 212-00328 | Spring - Extension | 1 |
| | 975-00552 | Tie - Type-16, Nylon | 2 |
| | 934-00307 | Screw | 2 |
| 8 | 448-00935 | Chain - Door Restraint | 1 |
| 9 | 548-01867 | Ballast - 2 Lamp 40 Watt, 60 Hz. | 1 |
| | 448-12871 | Ballast - 2 Lamp 40 Watt, 50/60 Hz. (European) | 1 |
| | 934-00457 | Screw | 2 |
| 10 | 548-01845 | Filter Assembly | 1 |
| | 934-00307 | Screw | 2 |
| 11 | 448-01532 | Transformer - 115V | 1 |
| | 548-21534 | Transformer & Bracket Assembly - 220V | 1 |
| | 934-00324 | Screw | 2 |
| 12 | 548-01873 | Enclosure W/A - Blower | 1 |
| 13 | 548-01846 | Blower & Heater Outlet Assembly | 1 |
| | 448-04622 | Heater Assembly | 1 |
| | 448-01886 | Blower Assembly | 1 |
| | 448-04544 | Blower Motor Only | 1 |
| 14 | 448-01916 | Cash Box W/A | 1 |
| 15 | 526-02186 | Switch - Door Interlock | 1 |
| 16 | 448-00575 | Leg - Door | 1 |
| | 934-00307 | Screw | 3 |
| 17 | 448-02496 | Bracket - Interlock Switch Mounting | 1 |
| | 934-00307 | Screw | 2 |

Coin Mech Compartment



| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|-------------|--|-----------------------|
| 1 | 448-01591 | Switch, Coin Mech Door Interlock | 1 |
| | 548-00810 | Bracket, Switch Mounting | 1 |
| 2 | 448-00487 | Bracket, Locking - Top | 1 |
| | 934-00307 | Screw | 2 |
| 3 | 500-01000-6 | Universal Control Board Assembly - See Fig. 17 | 1 |
| 4 | 448-01417 | Latch Assembly, Main Door | 1 |
| | 934-00307 | Screw | 8 |
| 5 | 548-01407 | Stop Assembly, Message Center | 1 |
| | 934-00151 | Screw | 2 |
| 6 | 448-12416 | Lever and Actuator Assembly, to Coin Return | 1 |
| | 448-02457 | Lever, Actuator Assembly to Coin Mech Door | 1 |
| | 448-02459 | Bracket, Lever Mounting | 1 |
| | 448-02458 | Lever, Coin Mech Roller Actuator | 1 |
| | 133-00481 | Spring, Lever Return | 1 |
| | 448-02480 | Step Washer, Lever Pivot | 1 |
| | 934-00307 | Screw, Lever Pivot | 1 |
| 7 | 448-02563 | Bracket, Coin Mech Position | 1 |
| | 448-02560 | Link - Nest Stop (Not Shown) | 2 |
| | 448-02562 | Pivot - Link (Not Shown) | 2 |
| 8 | 448-00418 | Hook - Locking | 1 |
| 9 | 448-2560 | Link - Nest Stop | 1 |
| | 448-2562 | Pivot - Link | 1 |
| 10 | 448-12468 | Nest, Coin Mech and UBA Mounting | 1 |
| | 448-12469 | Nest, Rivet and Weld Assembly | 1 |
| | 448-02481 | Pivot, Actuator | 2 |
| | 448-02556 | Plate, Swivel - Coin Mech Mounting | 1 |
| | 448-02561 | Slide Latch - Nest Assembly | 1 |
| | 950-00045 | Washer | 1 |
| | 132-00069 | Spring, Latch | 1 |
| 11 | 448-66019 | Universal Bill Acceptor | OPT |
| 12 | 448-12402 | Coin Chute W/A - (To Coin Return Cup) | 1 |
| 13 | 448-02559 | Pivot Shaft - Coin Mech Nest | 1 |
| | 448-02472 | Keeper, Pivot Shaft | 1 |
| 14 | 448-12470 | Coin Chute W/A - (To Cash Box) | 1 |
| 15 | 448-00485 | Bracket, Locking - Bottom | 1 |
| 16 | 448-02472 | Keeper - Coin Mech | 1 |
| 17 | 448-02469 | Bracket - Pivot CBA | 1 |
| 18 | 548-01406 | Mounting Plate R/A - Coin Mech Socket | 1 |
| | 548-00435 | Bracket - Mounting, Coin Mech Socket | 1 |
| | 548-01825 | Harness - UCB to Coin Mech Socket | 1 |
| | 909-00022 | Pin - Drive, .073 x 1" | 1 |
| | 975-00549 | Tie Type 16 - Nylon | 1 |
| | 924-00177 | Nut | 1 |
| | 548-00499 | Retainer, Coin Mech Plug (Large) | 1 |
| | 448-02477 | Retainer, Coin Mech Plug (Small) | 1 |
| | 408-00431 | Knob, Torque (Not Shown) | 1 |
| - | 548-01884 | Harness (Solenoid Protection) (UCB P-16) (Not Shown) | 1 |


Door Assembly, Coin Mech Compartment



| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|-------------|--|-----------------------|
| | 548-4508 | Coin Mech Compartment Door - Complete w/ Award Styling (Euro.) | REF |
| | 548-4509 | Coin Mech Compartment Door - Complete w/ Imp. Crown Styling (Dom.) | REF |
| | 548-4510 | Coin Mech Compartment Door - Complete w/ Genesis Styling (Dom.) | REF |
| | 548-4511 | Coin Mech Compartment Door - Complete w/ Award Styling (Dom.) | REF |
| | 548-4512 | Coin Mech Compartment Door - Complete w/ Award Styling (Euro.) | REF |
| 1 | 548-00433 | Latch Spring, Message Center | 1 |
| | 924-00054 | Nut 2 | |
| 2 | 448-00733 | Bracket, Coin Mech Door Lock Bar | 1 |
| | 934-00151 | Screw | 2 |
| | 448-02417 | Lock Bar, Coin Mech Door | 1 |
| | 933-00004 | Retaining Ring | 2 |
| 3 | 448-01549 | Cam, Lock Bar Actuator | 1 |
| | 448-00734 | Spacer, "T" Handle Nut | 1 |
| | 924-00181 | Nut, "T" Handle | 1 |
| | 548-01402 | Door Assembly, Coin Mech Compartment | REF |
| | 548-01404 | Door R/A, Coin Mech Compartment | 1 |
| 4 | 548-01422 | Coin Insert Assembly | 1 |
| 5 | 448-02426 | Chute, Coin Return | 1 |
| 6 | 448-02427 | Back Chute, Coin Return | 1 |
| 7 | 448-21510 | Cup, Coin Return | 1 |
| | 490-00409 | Flap, Coin Return Cup | 1 |
| | 490-00424 | Pivot Shaft, Coin Return Flap | 1 |
| | 941-00008 | Speed Nut, Pivot Shaft | 1 |
| | 934-00320 | Screw, Coin Return Cup Mounting | 5 |
| | 924-00054 | Nut, Chute Mounting | 2 |
| 8 | 448-02565 | Hinge, Coin Mech Compartment Door | 1 |
| 9 | 548-01414 | Bracket W/A - Coin Insert | 1 |
| | 934-00324 | Screw, Bracket Mounting | 4 |
| 10 | 448-02424 | Coin Chute | 1 |
| | 448-02425 | Backing Plate, Coin Chute (Gate) | 1 |
| | 934-00151 | Screw | 5 |
| 11 | 448-12408 | Lever & Nut, Coin Return | 1 |
| | 921-00026 | Screw, Coin Return Lever | 1 |
| | 924-00006 | Nut, Coin Return Lever | 1 |
| 12 | 490-00435 | Pivot Shaft, Coin Return | 2 |
| | 933-00005 | Retaining Ring | 3 |
| 13 | 490-00498 | Spring, Lever Return | 1 |

| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|---------------|--|-----------------------|
| | 548-01403 | Delivery Door Panel Assembly | REF |
| 1 | 548-01410 | Delivery Door Latch Assembly - Complete - 4" | 9 |
| | 448-01434 | Latch Plate Rivet Assembly - 4" | 9 |
| | 548-01411 | Delivery Door Latch Assembly - Complete - 5" | 2 |
| | 448-01435 | Latch Plate Rivet Assembly - 5" | 2 |
| 2 | 548-01857 | Solenoid and Diode Assembly - Unlatch | 11 |
| 3 | 448-00510 | Interlock Slide 4" | 8 |
| | 448-00511 | Interlock Slide 5" | 2 |
| 4 | 448-01403-003 | Spool and Spring Assembly | 11 |
| | 448-00443 | Drum, Delivery Door Spring | 11 |
| | 448-00513 | Spring, Delivery Door Return | 11 |
| 5 | 448-00509 | Guide, Locking Slide | 11 |
| 6 | 448-00495 | Pawl, Latch Mechanism | 11 |
| 7 | 448-00508 | Stop, Pawl | 11 |
| 8 | 933-00004 | "E" Ring | 33 |
| 9 | 21256201 | Spring, Lockout and Tension (Silver) | 22 |
| 10 | 448-01411 | Switch Actuator Link - (Not Visible) | 11 |
| 11 | 448-00492 | Stop, Delivery Door | 9 |
| | 448-00723 | Spacer - Large Compartment (Not Shown) | 2 |
| 12 | 490-00908 | Bumper, Delivery Door (Not Visible) | 12 |
| 13 | 548-01841 | Switch Assembly, Delivery Door (Includes Mounting Bracket) | 9 |
| 14 | 448-12806 | Latch Link R/A - (Includes Solenoid Plunger) | 11 |
| 15 | 448-00432 | Latch | 11 |
| 16 | 448-00434 | Link, Reset | 11 |
| 17 | 448-00514 | Spring, Delivery Door Latch | 11 |
| 18 | 548-01408 | "Z" Bracket and Switch Assembly (Includes Switch) | 1 |
| | 448-01409 | "Z" Bracket and Pin | 1 |
| | 548-01817 | Switch Door Interlock | 1 |
| | 448-00460 | "Z" Runner Mounting | 1 |
| 19 | 548-01817 | Switch, Motor Interlock (Switch Only) | 1 |
| | 548-00454 | Bell Crank - Switch Actuating | 1 |
| 20 | 548-00474 | Retainer, Actuator Return Spring | 1 |
| 21 | 333-00454 | Spring, Actuator Return | 1 |
| 22 | 548-00458 | Interlock Slide - Top Door Assembly - ONLY | 1 |
| 23 | 448-00813 | Actuator - Top and Bottom | 2 |
| | 921-00037 | Screw | 2 |


Cabinet Final Assembly




| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|-------------|--|-----------------------|
| | 548-01300 | Cabinet Final Assembly | REF |
| | 548-01305 | Cabinet Weld Assembly | 1 |
| 1 | 448-01309 | Top Pivot Plate - Also in Fig. 2 | 1 |
| | 934-00291 | Bolt (Not Shown) | 2 |
| | 903-00005 | Carriage Bolt (Not Shown) | 1 |
| | 924-00160 | Nut (Carriage Bolt) (Not Shown) | 1 |
| 2 | 548-00461 | Retainer, Liner Top | 1 |
| 3 | 448-12883 | Magnet and Bracket Assembly | 1 |
| | 929-00154 | Rivet | 2 |
| 4 | 448-02009 | Hat, Bearing Bracket (See Detail 9.1) | 1 |
| | 916-00208 | Grommet - Insulator, Type 12 | 4 |
| | 448-02916 | Insulation - Pivot Mounting Bracket | 1 |
| | 448-12108 | Bearing Bracket | 1 |
| 5 | 448-02010 | Bearing, Pivot Shaft (See Detail 9.1) | 1 |
| 6 | 448-02012 | Shaft, Upper Pivot (See Detail 9.1) | 1 |
| 7 | 448-02013 | Bracket, Pivot Shaft Mounting (See Detail 9.1) | 1 |
| | 934-00307 | Screw | 4 |
| 8 | 448-02014 | Pin Clevis | 1 |
| | 905-00051 | Hair Pin (Clevis Pin Retaining) | 1 |
| 9 | 448-02349 | Hook, Main Door Latching | 2 |
| | 934-00199 | Screw, Hook Mounting | 6 |
| 10 | 448-02333 | Liner, Cabinet | 1 |
| 11 | 448-12901 | Shelf, Storage | 4 |
| 12 | 548-01901 | Divider, Shelf and Reinforcement W/A | 1 |
| 13 | 548-00460 | Retainer, Liner R/H Side | 1 |
| 14 | 448-44004 | Bracket, Shelf Mounting | 2 |
| 15 | 448-12308 | Screen, Turret Tray - Also in Fig. 14 | 1 |
| 16 | 448-12306 | Screen, Rear Exhaust (Back of Cabinet) | 1 |
| 17 | 906-00517 | Data Plate - 548 | 1 |
| 18 | 907-00928 | Warning Label - "Tighten Screws" | 1 |
| 19 | 548-00311 | Cover, Refrigeration Unit - R/H Side | 1 |
| | 448-12205 | Refrigeration Unit Assembly - See Fig 16 | REF |
| 20 | 408-01316 | Leg, Assembly (Includes Leveler) | 4 |
| | 934-316 | Bolt 12 | |
| 21 | 408-00352 | Leveler Only | 4 |
| 22 | 548-01509 | Power Supply Final Assembly - See Fig. 10 | 1 |
| | 548-01505 | Power Supply Cover | 1 |
| 23 | 907-02222 | Label - "Screen Removal" | 1 |
| 24 | 548-01321 | Hinge & Pin Assembly - R/H | 1 |
| | 934-00450 | Screw | 2 |
| 25 | 907-02217 | Label - "Service Switch Instructions" | 1 |
| 26 | 907-02193 | Label - "Caution Power Supply" | 1 |
| 27 | 548-01322 | Hinge & Pin Assembly - L/H | 1 |

(Continued on next page)



Cabinet Final Assembly (Continued)



| Index No. | Part Number | Description | Quantity Per Assembly |
|------------------------|-------------|--|-----------------------|
| | 934-00450 | Screw | 2 |
| 28 | 448-00935 | Chain - Door Stop | 1 |
| | 921-00365 | Screw | 1 |
| 30 | 548-00342 | Cover - Refrigeration Unit -Left | 1 |
| | 548-01424 | Line Filter Assembly - Export Only | 1 |
| | 938-05000 | Line Filter- Export Only | 1 |
| | 25166910 | Terminal Block- Export Only | 1 |
| | 548-00524 | Bracket - Filter- Export Only | 1 |
| | 548-01000 | Harness Assembly- Export Only | 1 |
| | 548-00342 | Cover- Export Only | 1 |
| 31 | 448-12845 | Main Switch Power Assembly | 1 |
| 32 | 448-00056 | Cover - Turret Drive | 1 |
| 33 | 448-12600 | Main Plate Assembly | 1 |
| 34 | 448-00606 | Retainer, Shelf | 7 |
| | 448-00612 | Column Separator | 7 |
| | 934-00486 | Screw | 14 |
| | 941-00078 | Speed Nut | 7 |
| | 941-00077 | Speed Nut | 7 |
| 35 | 548-01600 | Center Column Rivet Assembly - 11 Shelf | 1 |
| 36 | 548-00459 | Retainer, Liner L/H Side | 1 |
| 37 | 548-01308 | Condenser Screen W/A (See Fig. 11) | 1 |
| | 941-00092 | Clip, Condenser Screen (Not Shown) (See Fig. 11) | 2 |
| 38 | 448-02007 | Plate - Turret, Upper | 1 |
| 39 | 448-01306 | Bracket, Pivot Assembly | 1 |
| Product Shelves | | | |
| | 448-02601 | Split 4" | |
| | 448-00600 | Platter 4 & 5" | |
| | 448-01607 | Over/Under | |
| | 448-02602 | Split 5" | |
| | 448-02601 | Split 4" | |

Detail 9.1

Power Supply Assembly




Outside of the Refrigeration Cover
(Power Supply Closed)

| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|-------------|-------------------------------------|-----------------------|
| | 548-01509 | Power Supply Assembly - Complete | REF |
| 1 | 548-01890 | Power Supply - Only | 1 |
| | 280-01101 | PCB Assembly - Power Supply | 1 |
| | 280-70601 | Cover - PCB | 1 |
| 2 | 548-01508 | Cover - Refrigeration Unit | 1 |
| 3 | 548-01508 | Transformer | 1 |
| | 924-00054 | Nut | 4 |
| 4 | 548-01845 | Line Filter | 1 |
| 5 | 912-00077 | Circuit Breaker, 3 Amp | 1 |
| | 950-00176 | Lockwasher | 2 |
| 6 | 938-08001 | Relay (24 VDC - 15 Amp) | 2 |
| | 924-00054 | Nut | 4 |
| 7 | 548-01510 | Harness - Power Supply | 1 |
| 9 | 700-73601 | Circuit Breaker - 1/2 Amp. | 1 |
| 10 | 700-73608 | Circuit Breaker - 5 Amp. | 3 |
| 11 | 548-00828 | Cover - Backup Refrigeration | 1 |
| 12 | 548-01870 | PCB Assembly - Backup Refrigeration | 1 |
| | 70500004 | Support - Circuit Board | 4 |

This document is available free of
charge to our customers
www.automaticproducts.com


Main Power Switch




| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|-------------|--|-----------------------|
| | 448-12845 | Main Switch Assembly - Complete | REF |
| | 548-21528 | Switch Panel Assembly European (Not Shown) | 1 |
| 1 | 301-01711 | Switch, Main Line | 1 |
| | 939-01252 | Insulation, Fishpaper - Main Line Switch | 1 |
| 2 | 921-00287 | Screw | 2 |
| 3 | 950-00349 | Lockwasher | 2 |
| 4 | 912-00049 | Circuit Breaker, Refrigeration Unit - 20 Amps | 1 |
| | 912-00046 | Circuit Breaker, Refrigeration Unit - 10 Amps (European) | 1 |
| 5 | 912-00050 | Circuit Breaker, Vend Power - 7 Amps | 1 |
| | 912-00056 | Circuit Breaker, Vend Power - 5 Amps (European) | 1 |
| 6 | 950-00112 | Washer | 2 |
| 7 | 448-12848 | Switch, Refrigeration Compressor | 1 |
| 8 | 448-02819 | Spring, Refrigeration Compressor Switch Actuator | 1 |
| 9 | 979-01275 | Receptacle, Refrigeration Power Cord | 1 |
| 10 | 979-01207 | Socket - Vend Circuit Harness Plug | 1 |
| 11 | 448-12846 | Switch Panel w/ Silkscreen | 1 |

This document is available free of
charge to our customers
www.automaticproducts.com


Turret Drive Motor



| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|-------------|--|-----------------------|
| | 548-01814 | Drive Motor, Switch and Plate Assembly - Complete | REF |
| 1 | 448-00041 | Plate, Bearing | 1 |
| 2 | 934-00199 | Screw | 4 |
| 3 | 448-00071 | Plate, Drive Motor Mounting | 1 |
| 4 | 548-01815 | Drive Motor and Gear Box, Transport | 1 |
| 5 | 448-06022 | Coupling Kit | 1 |
| | 548-01314 | Coupling Assembly - Back | 1 |
| | 448-00085 | Coupling - Front | 1 |
| | 947-00020 | Screw | 4 |
| | 950-00385 | Washer | 4 |
| | 448-00096 | Pin, Height Adjustment - (Not Shown) | 1 |
| 6 | 947-00020 | Screw | 4 |
| | 950-00385 | Washer | 4 |
| 7 | 548-00011 | Plate, Transport Motor Switch Mounting | 1 |
| 8 | 921-00211 | Screw | 4 |
| | 924-00059 | Nut | 4 |
| 9 | 939-00954 | Insulation | 1 |
| 10 | 421-04503 | Switch, Transport Motor | 1 |
| | 934-00210 | Screw | 2 |
| 11 | 448-00087 | Cam, Switch Actuator | 1 |
| 12 | 921-00309 | Machine Screw | 1 |
| | 950-00052 | Washer | 1 |
| | 924-00054 | Nut | 1 |
| | 548-01838 | Harness, Transport Motor and Half Cycle Switch (See Below) | REF |
| 13 | 913-00031 | Fuse Holder | 1 |
| | 912-00015 | Fuse 3.2 Amp | 1 |




Turret Components (Bottom)



| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|-------------|-----------------------------|-----------------------|
| | 448-12600 | Main Plate Assembly | REF |
| 1 | 448-00606 | Retainer, Shelf | 7 |
| 2 | 448-00095 | Cam - Turret Drive (Molded) | 14 |
| | 934-00492 | Screw | 56 |
| 3 | 448-02002 | Ring, Air-Sealed | 1 |
| | 934-00154 | Screw | 5 |
| 4 | 448-02600 | Plate - Main Turret | 1 |


Turret Drive & Roller



This document is available free of
charge to our customers
www.automateddescriptions.com

| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|-------------|--|-----------------------|
| | 448-12106 | Plate Assembly - Roller Guide | REF. |
| 1 | 448-01028 | Drive Shaft & Bearing Assembly | 1 |
| | 448-00061 | Cam Follower | 2 |
| | 448-01029 | Drive Arm | 1 |
| | 924-00064 | Nut | 2 |
| | 950-00090 | Washer - Flat | 2 |
| 2 | 448-01033 | Housing & Plate & Bearing Assembly | 1 |
| | 934-00452 | Screw, Self Tapping | 3 |
| 3 | 448-12105 | Lower Plate Weld Assembly | 1 |
| | 934-00452 | Screw, Self Tapping | 7 |
| 4 | 448-00081 | Roller | 8 |
| | 448-00090 | Shoulder Bolt | 8 |
| 5 | 448-12107 | Roller Guide Plate Weld Assembly | 1 |
| 6 | 916-00091 | Grommet | 1 |
| 7 | 448-02001 | Ring Turret - Lower | 1 |
| 8 | 448-12308 | Screen Weld Assembly, Turret Tray - See Fig. 9 | 1 |


Lock Bar Solenoid



This document is available free of charge to our customers
www.automaticproducts.com

| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|-------------|---------------------------------------|-----------------------|
| | 548-01403 | Delivery Door Panel Assembly | REF |
| 1 | 448-01867 | Switch, Lock Bar | 2 |
| | 934-00125 | Screw, Switch Mounting | 2 |
| | 941-00051 | Tinnerman Nut, Switch Mounting | 1 |
| | 448-000453 | Bracket, Lock Bar Switch Mounting | 1 |
| | 939-00954 | Insulator, Fishpaper | 1 |
| 2 | 448-01040 | Lock Bar Assembly | 1 |
| 3 | 548-01854 | Solenoid and Diode Assembly, Lock Bar | 1 |
| | 448-00642 | Plate, Solenoid Mounting | 1 |
| | 934-00307 | Screw, Mounting Plate | 2 |
| 4 | 448-00722 | Anti-Spread Bar | 1 |
| 5 | 905-00012 | Cotter Pin | 1 |

Refrigeration Unit




| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|--|---|-----------------------|
| | 548-21531 | Refrigeration Unit Assembly - Complete, R502 220/240V 50/60 HZ | REF |
| | 548-21559 | Refrigeration Unit Assembly - Complete, R404a 220/240V 50/60 HZ | REF |
| | 548-01208 | Refrigeration Unit Assembly - Complete, R404a 120V 60 HZ | REF |
| | 448-12205 | Refrigeration Unit Assembly - Complete, R502 120V 60 HZ | REF |
| 1 | 448-12209 | Refrigeration Unit Base and Stud Assembly | 1 |
| 2 | 448-12210 | Compressor - R502 120V 60 HZ | 1 |
| | 548-01207 | Compressor - R404a 120V 60 HZ | 1 |
| | 548-21558 | Compressor - R404a 220/240 V 50/60 HZ | 1 |
| | 548-21524 | Compressor - R502 220/240 V 50/60 HZ | 1 |
| 3 | 448-12215 | Condenser Coil Assembly | 1 |
| | 866-80005 | Gasket, Rubber (Bulk Number) | A/R |
| | 2 Pieces 9 1/4" Long, 1 Piece 13 1/2" Long | | |
| 4 | 448-02225 | Shroud, Condenser Unit Assembly | 1 |
| 5 | 448-02246 | Drip Tray | 1 |
| 6 | 448-12221 | Condenser Fan Assembly - Complete Consists of: | 1 |
| | 448-02226 | Blade, Condenser Fan | 1 |
| | 448-01228 | Motor, Condenser Fan | 1 |
| | 448-02215 | Bracket, Condenser Fan Mounting | 1 |
| | 924-00062 | Nut, Fan Assembly Mounting | 2 |

Fig. 16**548 Showcase Merchandiser**

| Index No. | Part Number | Description | Quantity Per Assembly |
|-----------|-------------|---|-----------------------|
| 7 | 448-02247 | Cover, Evaporator | 1 |
| | 866-55001 | Gasket, Cover (56" Required) | A/R |
| 8 | 448-12212 | Air Return Housing Assembly - Complete | 1 |
| | 448-02243 | Gasket Only - Air Return | 1 |
| 9 | 448-01829 | Temperature Control Thermostat (Backup Refrigeration) (Not Shown) | 1 |
| | 595-20501 | Cover, Thermostat (Cold Control Backup) | 1 |
| 10 | 448-12211 | Service Valve Assembly - Complete High Side and Low Side | 2 |
| | 448-12219 | Valve Core Only (Schrader) | 2 |
| | 448-12220 | Cap and Seal - Service Valve | 2 |
| 11 | 448-02242 | Gasket, Evaporator Output | 1 |
| 12 | 448-12225 | Evaporator and Bracket R/A (Inside Housing) | 1 |
| | 448-12216 | Evaporator Only | 1 |
| | 448-02219 | Bracket - Evaporator Mounting. (Right) | 1 |
| | 448-02260 | Bracket - Evaporator Mounting. (Left) | 1 |
| | 929-00043 | Rivet | 1 |
| 13 | 448-12222 | Blower and Bracket Assembly, Evaporator | 1 |
| | 548-01855 | Blower Motor Only | 1 |
| | 595-21526 | Squirrel Cage Only | 1 |
| | 448-02248 | Bracket, Blower Motor Mounting | 1 |
| | 916-00207 | Grommet, Blower Mounting | 1 |
| | 448-02264 | Gasket, Blower | 1 |
| 14 | 548-01895 | Control Box Assembly - Complete Consists of: | 1 |
| | 448-02817 | Base - Control Box | 1 |
| | 448-02818 | Cover - Control Box | 1 |
| | 448-12849 | Start Relay, Compressor | 1 |
| | 936-01002 | Capacitor, Starting 72-88 mfd. @ 250V | 1 |
| | 448-02821 | Clamp, Start Capacitor | 2 |
| | 936-01003 | Capacitor, Run - 25 mfd. @ 330V | 1 |
| | 448-02822 | Clamp, Run Capacitor | 1 |
| | 548-01886 | Snubber Assembly (In Control Box) | 1 |
| | ***** | All Harnesses are included in 448-12847 Assembly | |
| 15 | 448-02241 | Lever, Refrigeration Unit Securing | 2 |
| | 448-02249 | Bushing, Lever Pivot | 2 |
| | 950-00030 | Washer | 2 |
| | 921-00193 | Screw | 2 |
| 16 | 111-01217 | Accumulator, Suction Side | 1 |
| 17 | 595-21513 | Drier, Liquid Line | 1 |
| 18 | ***** | Thermo-Overload - Under Cover (Comes With P/N 448-12210 Only) | 1 |
| | **** | Start Relay | 1 |
| 19 | 70709101 | High Pressure Cutout Switch | 1 |
| 20 | 44802956 | Baffle Evaporator | |

Refrigeration Harnesses

| | | |
|-----------|---|---|
| 448-12867 | Harness, Compressor to Cold Control | 1 |
| 448-12866 | Power Cord Assembly - Refrigeration Unit Assembly | 1 |
| 548-01887 | Snubber Assembly (In Evaporator Fan Harness) | 1 |
| 548-01513 | Harness, Thermostat to Refrig. and Backup Relay (Not Shown) | 1 |
| 548-01896 | Harness Evaporator & Condenser Fan | 1 |
| 548-01897 | Harness Compressor to Cold Control | 1 |
| 548-01898 | Harness - Compressor | 1 |

Universal Control Board


Universal Control Board

| Reference Number | Part Number | Description |
|-----------------------------|-------------|---------------------------------------|
| C58, C60 | 70028201 | Capacitor - 22 μ F, 50V Rad. |
| C18, C25, C50, C52 | 70025301 | Capacitor - 1 μ F, 35V 10% |
| C1, C26, C27, C54, C57, C59 | 70025302 | Capacitor - 15 μ F, 15V 10% |
| C49, C61 | 70025303 | Capacitor - 47 μ F, 10V 10% |
| C12, C13, C28, C29 | 70028705 | Capacitor - 22PF, 50V 10% |
| C2-C8, C10, C11, C14-17 | | |
| C19-C24, C30-C33, C35-C48 | | |
| C51, C53, C55, C56 | 70028649 | Capacitor - .1 μ F, 50V 10% |
| X2 | 25167327 | Xtal - Quartz, 10 MHz. |
| X1 | 25167318 | Xtal - Quartz, 3.6864 MHz. LS - .190" |
| D1, D2, D4, D5 | 70035012 | Diode 75V .075 Amp. |
| U21 | 30800270 | IC - Quad 2 input, |
| U17 | 30800216 | IC - Quad OP Amp. |
| Q1 | 30800243 | IC - Under Volt Sensor |
| U18 | 79940008 | IC - Quad 2 input and Gate CMOS |
| U10, U11 | 79940014 | IC - Hex Schmitt-Trig Inverter CMOS |
| U6 | 79940157 | IC - Quad 2 input Multiplexer |
| U19, U22, U25, U27, U28 | 79940273 | IC - Octal D-Flip Flop w/Clear |
| U13 | 79940573 | IC - Octal D-Latch Tri-State |
| U5 | 70033714 | IC - 2 Channel Optocoupler |
| U20 | 70036901 | IC - Darlington Array |
| U24, U26 | 70036906 | IC - High Current Source Driver |
| U29, U30, U33, U34 | 70036908 | IC - Quad - High Current, Darlington |
| U2, U3 | 30800271 | IC - Quad Line Driver |
| U4, U8 | 30800272 | IC - Quad Receiver |
| U9 | 70034704 | IC - Dual Uart |
| U15 | 70036609 | IC - SRAM Bat. 8K x 8 w/RTC |
| U16 | 28027101 | IC - UCB - Programmed |
| U23 | 70037145 | IC - Encoder, Priority IDPE-30 |
| U1 | 70036309 | IC - Hex Buffer Open |
| U32 | 70036518 | IC - Voltage Regulator, 12V Linear |
| U31 | 70036521 | IC - Voltage Regulator, -12 to -200 |
| R16 | 799122322 | Resistor - 23.2K 1/4 Watt 1% |
| R13 | 799123462 | Resistor - 34.8K 1/4 Watt 1% |
| R14 | 799121003 | Resistor - 100K 1/4 Watt 1% |
| R15, R17-R20, R22-R26 | 799121004 | Resistor - 1M 1/4 Watt 1% |
| R12 | 799124990 | Resistor - 499 OHM 1/4 Watt 1% |
| R3, R7, R8, R10, R11, R21 | 799001123 | Resistor - 12K 1/4 Watt 5% |
| R5, R9, R32 | 79904391 | Resistor - 390 OHM 1/2 Watt 5% |

Universal Control Board (Continued)

| Reference Number | Part Number | Description |
|--------------------|-------------|---------------------------------|
| R30, R31 | 79904392 | Resistor - 3.9K 1/2 Watt 5% |
| R28, R29, R33, R34 | 70714201 | Resistor - 20 OHM 5 Watt 5% |
| SW1 | 70043008 | Switch - Dip |
| D3, D6-D8 | 70035303 | LED - Visible, Red |
| U7 | 7994040107 | IC - Dual 2 Input Nand GT, CMOS |
| J2 | 70076410 | Connector - HDR, 10 Position |
| J3 | 70076412 | Connector - HDR 12 Position |
| J4 | 70076404 | Connector - HDR 4 Position |
| J5 | 70076416 | Connector - HDR 16 Position |
| J7 | 70080509 | Connector - HDR 9 Position |
| J9 | 70076403 | Connector - HDR 3 Position |
| J13 | 70076407 | Connector - HDR 7 Position |
| J6 | 70076406 | Connector - HDR 6 Position |
| J8 | 70076414 | Connector - HDR 14 Position |
| J10 | 70076408 | Connector - HDR 8 Position |
| J11 | 70076409 | Connector - HDR 9 Position |
| J12 | 70076405 | Connector - HDR 5 Position |
| J14 | 70076415 | Connector - HDR 15 Position |
| J15 | 70080512 | Connector - HDR 12 Position |
| J16 | 70080506 | Connector - HDR 6 Position |
| J17 | 70076402 | Connector - HDR 2 Position |
| J18 | 70078703 | Connector - HDR 3 Position |
| R1, R2 | 79901181 | Resistor - 180 OHM 1/4 Watt 5% |
| R4, R27 | 79901102 | Resistor - 1K 1/4 Watt 5% |
| XU15 | 70073929 | Socket - IC |
| XU-12 | 25236201 | Socket - IC |
| XU14 | 70073928 | Socket - IC |

Power Supply Circuit Board Assembly



Components List

Power Supply Circuit Board

| Reference | Description | C-Power P/N | Mfg Part Number |
|---|-----------------------------------|------------------|--------------------------|
| Q1 | XSTR, NPN 60V 3 Amp | 700033005 | Motorola 2N6121 |
| U2 | IC, H-Bridge Motor Driver | 230A-00LM18200T | Nat'l. Semi. LMD1820CT |
| U200 | IC, Volt Reg. Adj. Neg. 3A to 220 | 230A-0000LM350T | Motorola LM35CT |
| VR1 | PWM 5V | 230A-0LAS6330PI | Aavid 593002BC340C |
| VR2 | IC Volt. Reg. Adj. 5A to -3 | 230A-0000LM338K | Nat'l. Semi. LM 338K |
| F1 | Fuse Holder | 461A-250600-001 | Shurter CG 751.0099 |
| D17 | Diode 6V | 221A029-00ICTE5 | Gen. Semi. ICTE-5 |
| P2, P3 | Fuse 1 Amp 125 VAC | 262A1R00125A-01 | Littlefuse 251CC1 |
| C35 | Cap. 220 MFD 50V 20% | 203A7F6100-2207 | Panasonic ECCE1HV102S |
| C2, C4, C27, C108 | Cap. 1000 MFD 50V 20% | 203A7F6100-1008 | Panasonic ECCE1HV102S |
| C8, C200 | Cap. 4700 MFD 50V 20% | 203A7C6100-4708 | Panasonic ECCE1HU472S |
| C15 | Cap. 2200 MFD 15V 20% | 203A7F6100-2208 | Panasonic ECCE1CF222 |
| C16, C18, C21 C22, C31 | Cap. 15UF 15V 10% | 70025302 | Sprague 173D156X9015W |
| C9, C24 | Cap. 47UF 63V 20% | 203A7T6000-4706 | Sprague 515D476M100CD6A |
| C13 | Cap. 120 PF 100V 10% | 203A0F5110-1201 | AVX SA101A121KAA |
| C10 | Cap. 5600PF 100V 10% | 203A0H5120-5602 | AVX SA101C562KAA |
| C11, C12, C20, C23 C28, C30, C32, C33 C34, C36, C37, C300 | Cap. .1UF 50V 20% | 70028649 | Kemet C410C104M55U5CA |
| C3- C7, C25 C26, C29 | Cap. .01UF 100V 10% | 203A0H5120-1003 | AVX SA201C103KAA |
| C100-C107, C111, C112 | Cap. .01UF 1KV 20% | 203A9R6070-1003 | MPI GE103M |
| D15 | Diode, signal 75 PIV | 70035012 | Diodes, Inc. 1N4148 |
| D20-D23, D24 D108-D111 | Diode, 400V 1A DC-41 | 70035005 | Diode, Inc. 1N4004 |
| D10 | Diode, Schottky 40V | 220A004-C1N5822 | Motorola 1N5822 |
| C19 | Cap. .68UF 35V 10% | 203A6E5100-6804 | Sprague 173D684X9035V |
| C113, C114 | Cap. .001UF 1KV 20% | 203A0R7091-1001 | Sprague 5GAD10 |
| D104, D105 D106, D107 | Diode, Rect. 50V 6A | 220A028-00006A1 | Rectron 6A1 |
| D18 | Zener 5.1V 70035501 | Motorola 1N4733A | |
| F1 | Fuse 2Amp 125V | 262A2R000125D-01 | Littlefuse 312002 |
| J2 | Con. HDR. MTA100 | 350A06404563-00 | AMP 640456-3 |
| J6 | Con. HDR. MTA100 | 350A16404562-00 | AMP 1-640456-2 |
| D2, D3, D4, D5, D100-D103, D112, D113 D114, D115, D200 | Diode, Rect. 100V 3A | 70035004 | Diodes, Inc. 1N5401 |
| J9 | Con. HDR. MTA156 | 350A06404458-00 | AMP 640445-8 |
| J1 | Con. HDR. 7 Pin .156 Centers | 350A06404457-00 | AMP 640445-7 |
| J7 | Con. HDR. MTA156 | 70080509 | AMP 640445-9 |
| J5 | Con. HDR. MTA156 | 350A16404450-00 | AMP 1-640445-0 |
| J4 | Con. HDR. MTA156 | 350A16404453-00 | AMP 1-640445-3 |
| U4 | IC LM10CN OP-AMP | 230A-0000LM10CN | National LM10CN |
| U5 | IC, Overvoltage Sens. | 230A-000003423P | Motorola MC3423R1 |
| U3 | IC, Digital Quad. | 232A-000074HC02 | National Semi. MM74HC02N |
| U1 | IC, RS232 | 230A-00IT1181CN | Linear Tech LT1181CN |
| L2 | Inductor, 1MH 4A | 206A1-1005-0001 | Dale IH-3-01 |
| L1 | Inductor, 220MH 5.5A | 206A3-2207-0001 | Renco RL-4435-285-3.0 |

Components List

Power Supply Circuit Board

| | | | |
|--------------------|-------------------------|-----------------|--------------------------|
| K1 | Relay, 24VDC 10 Amp | 244AGR2117P-VUS | OMCRCN G2R-1A-D024 |
| R26 | Resistor, 681 .25W 1% | 200A005002-6810 | TTI 5043ED681R0F |
| R25 | Resistor, 866 .25W 1% | 200A005002-8660 | TTI 5043ED866R0F |
| R21 | Resistor, 56 .25W 5% | 79901560 | Philips 5043CX56R00J |
| R7, R8, R11, R12 | Resistor, 100 .25W 5% | 79901101 | Philips 5043CX100R0J |
| R9 | Resistor, 220 .25W 5% | 79901221 | Philips 5043CX220R0J |
| R19 | Resistor, 270 .25W 5% | 79901271 | Philips 5043CX220R0J |
| R24 | Resistor, 1K .25W 5% | 79901102 | Philips 5043CX1K000J |
| R30 | Resistor, 1.5K .25W 5% | 79901152 | Philips 5043CX1K500J |
| R13, R22, R37 | Resistor, 1.8K .25W 5% | 79901182 | Philips 5043CX1K800J |
| R18, R20, R35, R38 | Resistor, 1K .25W 5% | 79901222 | Philips 5043CX2K200J |
| R5, R6, R14, R34 | Resistor, 4.7K .25W 5% | 79901472 | Philips 5043CX4K700J |
| R1 | Resistor, 22K .25W 5% | 79901223 | Philips 5043CX22K00J |
| R15, R17, R27, R28 | Resistor, 100K .25W 5% | 79901104 | Philips 5043CX100K0J |
| R29, R33 | | | |
| R10, R16 | Resistor, 1M .25W 5% | 79901105 | Philips 5043CX1M000J |
| R200 | Resistor, .47 5W 10% | 200A042044-SX47 | Dale CP5 - .47 - 10% |
| R23 | Resistor, 180 5W 10% | 200A042044-0181 | IRC PW - 5A - 180 - 5% |
| Q2 | Thyristor 60V .51 Amp | 266A4-0002N5061 | Motorola 2N5061 |
| TH2, TH100, TH101 | Thermistor | 215A-00RDE-305A | Raychem RDE-305A |
| R31, R32 | Resistor 330k .25W 5% | 79901334 | KOA RDS2 - 1/4 - 330K-5% |
| F2 | Fuse 1 Amp 125V | 262A1R00125A-01 | Littlefuse - 251001 |
| F3 | Fuse 1 Amp 125V | 262A1R00125A-01 | Littlefuse - 251001 |
| F4 | FUSE 3 Amp 125V | 262A3R00125A-01 | Littlefuse 251.003 |
| LED5 | LED Red / Green | 242A-01F02AS-01 | Qual. Tech. MV5491 |
| LED1, LED2, LED3, | LED Red | 242A-01F022S-01 | Lite On LTL-4203 |
| LED4, LED6, LED7 | | | |
| LP1, LP2, LP3, LP5 | Lamp, Neon Blue | 240A-CA1201B-01 | Alco NE - 1H |
| LP6, LP7 | | | |
| R4 | Resistor, 4.75K .25W 1% | 200A005002-4751 | PHILIPS 5043ED4K750F |
| JB | CON. HDRMTA-156 | 350A06404434-00 | |

Harness List

Internal Harness Assemblies

| | |
|-----------------|--|
| 548-01835 | Harness - Door Power Panel |
| 548-01891 | Harness - Transformer Assembly |
| 548-01014 | Line Cord with Terminal (Main Power Cord) |
| 916-00108 | Grommet (Line Cord) |
| 500-01017 | Harness - Mess. Center Disp. to Mess. Center Keypad |

Point to Point Harnesses

| | From | TO |
|-----------|---|----------------------------|
| 548-01819 | Harness - Universal Control Board | P-2 Message Display Center |
| 548-01820 | Harness - Universal Control Board P-3 | Door Switches |
| 548-01822 | Harness - Universal Control Board P-5 | UBA, P-3 |
| 548-01825 | Harness - Universal Control Board P-8 | Coin Mech Socket |
| 548-01826 | Harness - Universal Control Board P-9 | Health Probe Socket |
| 548-01827 | Harness - Universal Control Board P-14 | Delivery Door Switches |
| 548-01828 | Harness - Universal Control Board P-15 | Door Solenoid |
| 548-01832 | Harness - Power Panel | Bulb Socket |
| 548-01833 | Harness - Door Power | UBA Power |
| 548-01874 | Harness - Door Panel | Blower and Heater |
| 548-01838 | Harness - Half Cycle Sw./Transport Mtr. | Connector |
| 548-01839 | Harness - Ballast | Door Power Panel |
| 548-01511 | Harness - Control Door | Cabinet |
| 548-01512 | Harness - Door Power | Cabinet |
| 548-01884 | Harness - UCB P16 | Solenoid Driver Protection |
| 548-01510 | Harness - Power Supply | Power Supply |
| 548-01513 | Harness - Cold Control | Power Supply |

European Part Numbers

| | |
|---------------|--|
| 548-20500 | Bezel - Coin Insert, Universal Control |
| 548-20501 | Plate - Mounting, Coin Mech, Europe |
| 548-20502 | Chute - Coin Return, Front, Europe |
| 548-20503 | Chute - Coin Return, Rear, Europe |
| 548-20504 | Bracket - Trans Mounting, Europe |
| 548-20505 | Bracket - Trans Retaining, Europe |
| 548-20509 | Overlay - Bezel, Selection, Charcoal Brown, UBA |
| 548-20510 | Overlay - Bezel, Selection, Black, UBA, French |
| 548-20511 | Overlay - Bezel, Charcoal Brown, German |
| 548-20512 | Overlay - Bezel, Black, German |
| 548-20513 | Overlay - Bezel, Universal, Brown, Spain |
| 548-20514 | Overlay - Bezel, Universal, Black, Spain |
| 548-21500-001 | Cabinet Final Assembly, European |
| 548-21500-002 | Cabinet Final Assembly, English |
| 548-21501 | Cabinet Assembly - European / English |
| 548-21520 | Door Final Assembly - European |
| 548-21521 | Door, Coin Mech - European |
| 548-21522 | Plate - Mounting Weld Assembly, European |
| 548-21523 | Hinge Assembly - Mounting Bracket, Coin Mech, European |
| 548-21524 | Compressor - European |
| 548-21525 | Motor - Condenser Fan, European |
| 548-21526 | Relay - Start, European |
| 548-21529 | Fan Assembly - Condenser, European |
| 548-21530 | Refrigeration Assembly, European - R502 |
| 548-21559 | Refrigeration Assembly, European - R404a |
| 548-21531 | Compressor Assembly, European - R502 |
| 548-21558 | Compressor Assembly, European - R404a |
| 548-21534 | Transformer and Bracket Assembly, 220V |
| 548-21535 | Panel, Switch and Silk Screen Assembly, European |
| 548-21536 | Isolation Transformer 750V AC |
| 548-21537 | Capacitor / Relay Box Assembly, European |
| 548-21539 | Power Cord - Compressor, European |
| 548-21540 | Harness, Evaporator and Condenser Fan - European |
| 548-21542 | Door - Coin Mech, Rivet Assembly, European |
| 548-21543 | Harness - Coin Mech Power, European |
| 548-21545 | Line Cord Asm. |
| 548-21546 | Hinge Assembly - Coin Mech Mounting Bracket |
| 548-21547 | Coin Mech Mounting Bracket |

Hardware List

| Part Number | Description |
|-------------|---|
| 448-00090 | Shoulder Bolt |
| 903-00005 | Carriage Bolt 1/4-20 x 5/8 |
| 903-00016 | Carriage Bolt - 10-24 x 5/8 |
| 905-00012 | Cotter Pin 1/8 X 3/4 |
| 905-00051 | Hitch Pin 3/16 |
| 914-00007 | Push Fastener |
| 921-00026 | Machine Screw - 10-32 x 3/4 RD |
| 921-00037 | Machine Screw - 6-32 x 3/16 BD |
| 921-00193 | Machine Screw - 1/4-20 x 1" Hex Head |
| 921-00211 | Machine Screw - 6-32 X 3/16 BD |
| 921-00240 | Machine Screw - 10-32 x 1/4" |
| 921-00287 | Machine Screw - 6-32 x 5" Hex Head Washer |
| 921-00309 | Machine Screw - 8-32 X 1 1/2 FIL |
| 921-00310 | Machine Screw - 8-32 x 5/16" Hex Head |
| 921-00365 | Machine Screw - 10-32 x 1/2 HX |
| 921-00496 | Machine Screw - 1/4-28 x 3/4 FLT |
| 924-00006 | Nut - 10-32 Type 1 |
| 924-00037 | Nut - 10-24 Type 1 |
| 924-00054 | Nut - 8-32 Type 6 |
| 924-00062 | Nut - 1/4-20 Type 6 |
| 924-00064 | Nut - 1/4-28 Type 6 |
| 924-00160 | Nut 5/16-18 Type 25 |
| 924-00176 | Nut - 3/16 Stud Type 11 |
| 924-00181 | Nut 1/2-20 Type 4 |
| 929-00154 | Rivet 1/8 x 1/4 Truss |
| 933-00004 | Retaining Ring - Type 10 - G=.250 |
| 933-00005 | Retaining Ring - Type 10 - G=.187 |
| 934-00029 | Screw - Self Tapping, #8 x 3/8" Type Z Hex Head |
| 934-00077 | Screw - Self Tapping, 6 x 3/16, Type-Z, STV |
| 934-00151 | Screw - Self Tapping, #8 x 1/4" Type Z Hex Washer Head |
| 934-00154 | Screw - Self Tapping, 8 x 3/8, Type Z Hex Washer Head |
| 934-00199 | Screw - Self Tapping, 10 x 3/8, Type Z Hex Head - Sems |
| 934-00210 | Screw - Self Tapping, 4-40 x 5/8, Type - 23, Hex |
| 934-00250 | Screw - Self Tapping, #6 x 1/4" Type Z Hex Washer Head - Sems |
| 934-00291 | Screw - Self Tapping, 5/16-18X1, Type - 23, Hex Washer Head |
| 934-00307 | Screw - Self Tapping, #8 x 3/8" Type Z Hex Washer Head - Sems |
| 934-00317 | Screw - Self Tapping, 8-32 x 5/16" Type 23 Hex Washer Head |
| 934-00320 | Screw - Self Tapping, 6-32 x 5/16" Type 23 Hex Washer Hd-Sems |
| 934-00324 | Screw - Self Tapping, 8-32 x 5/16, Type 23 Hex Washer Hd - Sems |
| 934-00350 | Screw - Self Tapping, 8-32 x 5/8, Type 23 Hex Washer Head |

Hardware List (Continued)

| | |
|-----------|--|
| 934-00357 | Screw - Self Tapping, 8-32 x 5/16, Type A Hex Washer Head - Sems |
| 934-00383 | Screw - Self Tapping, 8-32 x 3/8, Type - 23, FLT |
| 934-00419 | Screw - Self Tapping, 8-32 x 3/8" Type 23 Hex Washer Head |
| 934-00428 | Screw - Self Tapping, #8 x 3/8" Type Z Truss |
| 934-00443 | Screw - Self Tapping, #8 x 1-3/8" Type Z Truss |
| 934-00448 | Screw - Self Tapping, 8-18 x 1/2, Type-AB, Truss |
| 934-00450 | Screw - Self Tapping, 10-24 x 5/8, SLFDRL, Hex Washer Head |
| 934-00452 | Screw - Self Tapping, 10-9 x 3/4, LOTORQ., Hex Washer Head |
| 934-00457 | Screw - Self Tapping, #8X3/8, Type - Z, Truss |
| 934-00458 | Screw - Self Tapping, #8 x 5/8" PLT 30 Truss Hex Washer Head |
| 934-00485 | Screw - Self Tapping, #8 x 3/8" Type Z Truss Nib |
| 934-00486 | Screw - Self Tapping, 8 x 15/32, Type - Z, Truss Head Nib |
| 934-00492 | Screw - Self Tapping, 8 x 5/8, TY-Z, TRUSS |
| 934-00508 | Screw - Self Tapping, #8 x 5" Type 1 Truss |
| 941-00008 | Nut - Speed, Type 6 for 1/8" Stud |
| 941-00051 | Nut - Speed, Type -5 for #4 Screw |
| 941-00077 | Nut - Speed, Type - 26 for #8 Screw |
| 941-00078 | Nut - Speed, Type - 23 for #8 Screw |
| 941-00092 | Clip - Screen |
| 947-00020 | Screw - Socket Set 10-32 x 7/8 Type 2 |
| 950-00005 | Washer - 1/4" Flat |
| 950-00015 | Washer - #8 Flat |
| 950-00030 | Washer, # 1/4, Flat |
| 950-00045 | Washer, #6, Flat |
| 950-00052 | Washer - #8 Flat |
| 950-00090 | Washer - Flat |
| 950-00112 | Washer, # 1/4, Flat |
| 950-00226 | Washer - Locking |
| 950-00344 | Washer - #8 Locking |
| 950-00349 | Lockwasher - 8 split |
| 950-00383 | Washer - .251 Square Hole |
| 950-00385 | Washer #10 Lock |
| 975-00103 | Clip -Type 5, Nylon, D= 1/2 |
| 975-00552 | Tie -Type 16, Nylon |
| 975-00602 | Clip -Type 5, Nylon, D= 13/16 |

